



Sun Fire™ T1000 Server Service Manual

Sun Microsystems, Inc.
www.sun.com

Part No. 819-3248-13
January 2007, Revision A

Submit comments about this document at: <http://www.sun.com/hwdocs/feedback>

Copyright 2007 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A. All rights reserved.

Fujitsu Limited provided technical input and review on portions of this material.

Sun Microsystems, Inc. and Fujitsu Limited each own or control intellectual property rights relating to products and technology described in this document, and such products, technology and this document are protected by copyright laws, patents and other intellectual property laws and international treaties. The intellectual property rights of Sun Microsystems, Inc. and Fujitsu Limited in such products, technology and this document include, without limitation, one or more of the United States patents listed at <http://www.sun.com/patents> and one or more additional patents or patent applications in the United States or other countries.

This document and the product and technology to which it pertains are distributed under licenses restricting their use, copying, distribution, and decompilation. No part of such product or technology, or of this document, may be reproduced in any form by any means without prior written authorization of Fujitsu Limited and Sun Microsystems, Inc., and their applicable licensors, if any. The furnishing of this document to you does not give you any rights or licenses, express or implied, with respect to the product or technology to which it pertains, and this document does not contain or represent any commitment of any kind on the part of Fujitsu Limited or Sun Microsystems, Inc., or any affiliate of either of them.

This document and the product and technology described in this document may incorporate third-party intellectual property copyrighted by and/or licensed from Fujitsu Limited and/or Sun Microsystems, Inc., including software and font technology.

Per the terms of the GPL or LGPL, a copy of the source code governed by the GPL or LGPL, as applicable, is available upon request by the End User. Please contact Fujitsu Limited or Sun Microsystems, Inc.

This distribution may include materials developed by third parties.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and in other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, Java, Netra, Solaris, Sun StorEdge, SPARC Enterprise, docs.sun.com, OpenBoot, SunVTS, Sun Fire, SunSolve, CoolThreads, J2EE, and Sun are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

Fujitsu and the Fujitsu logo are registered trademarks of Fujitsu Limited.

All SPARC trademarks are used under license and are registered trademarks of SPARC International, Inc. in the U.S. and other countries. Products bearing SPARC trademarks are based upon architecture developed by Sun Microsystems, Inc.

SPARC64 is a trademark of SPARC International, Inc., used under license by Fujitsu Microelectronics, Inc. and Fujitsu Limited.

The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

United States Government Rights - Commercial use. U.S. Government users are subject to the standard government user license agreements of Sun Microsystems, Inc. and Fujitsu Limited and the applicable provisions of the FAR and its supplements.

Disclaimer: The only warranties granted by Fujitsu Limited, Sun Microsystems, Inc. or any affiliate of either of them in connection with this document or any product or technology described herein are those expressly set forth in the license agreement pursuant to which the product or technology is provided. EXCEPT AS EXPRESSLY SET FORTH IN SUCH AGREEMENT, FUJITSU LIMITED, SUN MICROSYSTEMS, INC. AND THEIR AFFILIATES MAKE NO REPRESENTATIONS OR WARRANTIES OF ANY KIND (EXPRESS OR IMPLIED) REGARDING SUCH PRODUCT OR TECHNOLOGY OR THIS DOCUMENT, WHICH ARE ALL PROVIDED AS IS, AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID. Unless otherwise expressly set forth in such agreement, to the extent allowed by applicable law, in no event shall Fujitsu Limited, Sun Microsystems, Inc. or any of their affiliates have any liability to any third party under any legal theory for any loss of revenues or profits, loss of use or data, or business interruptions, or for any indirect, special, incidental or consequential damages, even if advised of the possibility of such damages.

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.



Adobe PostScript

Copyright 2007 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, Etats-Unis. Tous droits réservés.

Entrée et revue tecnica fournies par Fujitsu Limited sur des parties de ce matériel.

Sun Microsystems, Inc. et Fujitsu Limited détiennent et contrôlent toutes deux des droits de propriété intellectuelle relatifs aux produits et technologies décrits dans ce document. De même, ces produits, technologies et ce document sont protégés par des lois sur le copyright, des brevets, d'autres lois sur la propriété intellectuelle et des traités internationaux. Les droits de propriété intellectuelle de Sun Microsystems, Inc. et Fujitsu Limited concernant ces produits, ces technologies et ce document comprennent, sans que cette liste soit exhaustive, un ou plusieurs brevets déposés aux États-Unis et indiqués à l'adresse <http://www.sun.com/patents> de même qu'un ou plusieurs brevets ou applications brevetées supplémentaires aux États-Unis et dans d'autres pays.

Ce document, le produit et les technologies afférents sont exclusivement distribués avec des licences qui en restreignent l'utilisation, la copie, la distribution et la décompilation. Aucune partie de ce produit, de ces technologies ou de ce document ne peut être reproduite sous quelque forme que ce soit, par quelque moyen que ce soit, sans l'autorisation écrite préalable de Fujitsu Limited et de Sun Microsystems, Inc., et de leurs éventuels bailleurs de licence. Ce document, bien qu'il vous ait été fourni, ne vous confère aucun droit et aucune licence, expresse ou tacite, concernant le produit ou la technologie auxquels il se rapporte. Par ailleurs, il ne contient ni ne représente aucun engagement, de quelque type que ce soit, de la part de Fujitsu Limited ou de Sun Microsystems, Inc., ou des sociétés affiliées.

Ce document, et le produit et les technologies qu'il décrit, peuvent inclure des droits de propriété intellectuelle de parties tierces protégés par copyright et/ou cédés sous licence par des fournisseurs à Fujitsu Limited et/ou Sun Microsystems, Inc., y compris des logiciels et des technologies relatives aux polices de caractères.

Par limites du GPL ou du LGPL, une copie du code source régi par le GPL ou LGPL, comme applicable, est sur demande vers la fin utilisateur disponible; veuillez contacter Fujitsu Limited ou Sun Microsystems, Inc.

Cette distribution peut comprendre des composants développés par des tierces parties.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux États-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, Java, Netra, Solaris, Sun StorEdge, SPARC Enterprise, docs.sun.com, OpenBoot, SunVTS, Sun Fire, SunSolve, CoolThreads, J2EE, et Sun sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc. aux États-Unis et dans d'autres pays.

Fujitsu et le logo Fujitsu sont des marques déposées de Fujitsu Limited.

Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux États-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

SPARC64 est une marque déposée de SPARC International, Inc., utilisée sous le permis par Fujitsu Microelectronics, Inc. et Fujitsu Limited.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciés de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui, en outre, se conforment aux licences écrites de Sun.

Droits du gouvernement américain - logiciel commercial. Les utilisateurs du gouvernement américain sont soumis aux contrats de licence standard de Sun Microsystems, Inc. et de Fujitsu Limited ainsi qu'aux clauses applicables stipulées dans le FAR et ses suppléments.

Avis de non-responsabilité: les seules garanties octroyées par Fujitsu Limited, Sun Microsystems, Inc. ou toute société affiliée de l'une ou l'autre entité en rapport avec ce document ou tout produit ou toute technologie décrit(e) dans les présentes correspondent aux garanties expressément stipulées dans le contrat de licence régissant le produit ou la technologie fourni(e). SAUF MENTION CONTRAIRE EXPRESSEMENT STIPULÉE DANS CE CONTRAT, FUJITSU LIMITED, SUN MICROSYSTEMS, INC. ET LES SOCIÉTÉS AFFILIÉES REJETTENT TOUTE REPRÉSENTATION OU TOUTE GARANTIE, QUELLE QU'EN SOIT LA NATURE (EXPRESSE OU IMPLICITE) CONCERNANT CE PRODUIT, CETTE TECHNOLOGIE OU CE DOCUMENT, LESQUELS SONT FOURNIS EN L'ÉTAT. EN OUTRE, TOUTES LES CONDITIONS, REPRÉSENTATIONS ET GARANTIES EXPRESSES OU TACITES, Y COMPRIS NOTAMMENT TOUTE GARANTIE IMPLICITE RELATIVE À LA QUALITÉ MARCHANDE, À L'APTITUDE À UNE UTILISATION PARTICULIÈRE OU À L'ABSENCE DE CONTREFAÇON, SONT EXCLUES, DANS LA MESURE AUTORISÉE PAR LA LOI APPLICABLE. Sauf mention contraire expressément stipulée dans ce contrat, dans la mesure autorisée par la loi applicable, en aucun cas Fujitsu Limited, Sun Microsystems, Inc. ou l'une de leurs filiales ne sauraient être tenues responsables envers un quelconque partie tierce, sous quelque théorie juridique que ce soit, de tout manque à gagner ou de perte de profit, de problèmes d'utilisation ou de perte de données, ou d'interruptions d'activités, ou de tout dommage indirect, spécial, secondaire ou consécutif, même si ces entités ont été préalablement informées d'une telle éventualité.

LA DOCUMENTATION EST FOURNIE "EN L'ÉTAT" ET TOUTES AUTRES CONDITIONS, DECLARATIONS ET GARANTIES EXPRESSES OU TACITES SONT FORMELLEMENT EXCLUES, DANS LA MESURE AUTORISÉE PAR LA LOI APPLICABLE, Y COMPRIS NOTAMMENT TOUTE GARANTIE IMPLICITE RELATIVE A LA QUALITE MARCHANDE, A L'APTITUDE A UNE UTILISATION PARTICULIERE OU A L'ABSENCE DE CONTREFAÇON.

Contents

- Preface** xiii

- 1. Safety Information** 1-1
 - 1.1 Safety Information 1-1
 - 1.2 Safety Symbols 1-1
 - 1.3 Electrostatic Discharge Safety 1-2
 - 1.3.1 Using an Antistatic Wrist Strap 1-2
 - 1.3.2 Using an Antistatic Mat 1-2

- 2. Server Overview** 2-1
 - 2.1 Server Overview 2-1
 - 2.2 Obtaining the Chassis Serial Number 2-3

- 3. Server Diagnostics** 3-1
 - 3.1 Overview of Server Diagnostics 3-1
 - 3.1.1 Memory Configuration and Fault Handling 3-6
 - 3.1.1.1 Memory Configuration 3-7
 - 3.1.1.2 Memory Fault Handling 3-7
 - 3.1.1.3 Troubleshooting Memory Faults 3-8
 - 3.2 Using LEDs to Identify the State of Devices 3-8
 - 3.2.1 Front and Rear Panel LEDs 3-10

- 3.2.2 Power Supply LEDs 3-11
- 3.3 Using ALOM CMT for Diagnosis and Repair Verification 3-11
 - 3.3.1 Running ALOM CMT Service-Related Commands 3-13
 - 3.3.1.1 Connecting to ALOM 3-13
 - 3.3.1.2 Switching Between the System Console and ALOM 3-14
 - 3.3.1.3 Service-Related ALOM CMT Commands 3-14
 - 3.3.2 Running the `showfaults` Command 3-16
 - 3.3.3 Running the `showenvironment` Command 3-17
 - 3.3.4 Running the `showfru` Command 3-19
- 3.4 Running POST 3-22
 - 3.4.1 Controlling How POST Runs 3-22
 - 3.4.2 Changing POST Parameters 3-26
 - 3.4.3 Reasons to Run POST 3-27
 - 3.4.3.1 Verifying Hardware Functionality 3-27
 - 3.4.3.2 Diagnosing the System Hardware 3-28
 - 3.4.4 Running POST in Maximum Mode 3-28
 - 3.4.5 Correctable Errors Detected by POST 3-35
 - 3.4.5.1 Correctable Errors for Single DIMMs 3-36
 - 3.4.5.2 Determining When to Replace Detected Devices 3-37
 - 3.4.6 Clearing POST Detected Faults 3-38
- 3.5 Using the Solaris Predictive Self-Healing Feature 3-39
 - 3.5.1 Identifying PSH Detected Faults 3-40
 - 3.5.1.1 Using the `fmddump` Command to Identify Faults 3-41
 - 3.5.2 Clearing PSH Detected Faults 3-44
- 3.6 Collecting Information From Solaris OS Files and Commands 3-45
 - 3.6.1 Checking the Message Buffer 3-45
 - 3.6.2 Viewing System Message Log Files 3-46

- 3.7 Managing Components With Automatic System Recovery Commands 3–46
 - 3.7.1 Displaying System Components 3–47
 - 3.7.2 Disabling Components 3–48
 - 3.7.3 Enabling Disabled Components 3–49
- 3.8 Exercising the System With SunVTS 3–49
 - 3.8.1 Checking Whether SunVTS Software Is Installed 3–49
 - 3.8.2 Exercising the System Using SunVTS Software 3–50
 - 3.8.3 Using SunVTS Software 3–51
- 4. Preparing for Servicing 4–1**
 - 4.1 Common Procedures for Parts Replacement 4–1
 - 4.1.1 Required Tools 4–2
 - 4.1.2 Shutting the System Down 4–2
 - 4.1.3 Removing the Server From a Rack 4–3
 - 4.1.4 Performing Electrostatic Discharge (ESD) Prevention Measures 4–5
 - 4.1.5 Removing the Top Cover 4–5
- 5. Replacing Field-Replaceable Units 5–1**
 - 5.1 Replacing the Optional PCI-Express Card 5–2
 - 5.1.1 Removing the Optional PCI-Express Card 5–2
 - 5.1.2 Installing the Optional PCI-Express Card 5–3
 - 5.2 Replacing the Fan Tray Assembly 5–4
 - 5.2.1 Removing the Fan Tray Assembly 5–4
 - 5.2.2 Installing the Fan Tray Assembly 5–5
 - 5.3 Replacing the Power Supply 5–5
 - 5.3.1 Removing the Power Supply 5–5
 - 5.3.2 Installing the Power Supply 5–6
 - 5.4 Replacing a Hard Drive 5–7

- 5.4.1 Replacing a Hard Drive in a Single-Drive Assembly 5–8
 - 5.4.1.1 Removing the Hard Drive in a Single-Drive Assembly 5–8
 - 5.4.1.2 Installing the Hard Drive in a Single-Drive Assembly 5–9
- 5.4.2 Replacing a Hard Drive in a Dual-Drive Assembly 5–10
 - 5.4.2.1 Removing a Hard Drive in a Dual-Drive Assembly 5–10
 - 5.4.2.2 Installing the Hard Drive in a Dual-Drive Assembly 5–12
- 5.5 Replacing DIMMs 5–14
 - 5.5.1 Removing DIMMs 5–14
 - 5.5.2 Installing DIMMs 5–16
- 5.6 Replacing the Motherboard and Chassis 5–20
 - 5.6.1 Removing the Motherboard and Chassis 5–20
 - 5.6.2 Installing the Motherboard and Chassis 5–20
- 5.7 Replacing the Clock Battery 5–22
 - 5.7.1 Removing the Clock Battery on the Motherboard 5–22
 - 5.7.2 Installing the Clock Battery on the Motherboard 5–22

6. Finishing Up Servicing 6–1

- 6.1 Final Service Procedures 6–1
 - 6.1.1 Replacing the Top Cover 6–1
 - 6.1.2 Reinstalling the Server Chassis in the Rack 6–1
 - 6.1.3 Applying Power to the Server 6–2

A. Field-Replaceable Units A–1

Index Index–1

Figures

- [FIGURE 2-1](#) Server 2-1
- [FIGURE 2-2](#) Server Components 2-2
- [FIGURE 2-3](#) Server Front Panel 2-2
- [FIGURE 2-4](#) Server Rear Panel 2-3
- [FIGURE 3-1](#) Diagnostic Flowchart 3-3
- [FIGURE 3-2](#) LEDs on the Server Front Panel 3-8
- [FIGURE 3-3](#) LEDs on the Server Rear Panel 3-9
- [FIGURE 3-4](#) ALOM CMT Fault Management 3-12
- [FIGURE 3-5](#) Flowchart of ALOM CMT Variables for POST Configuration 3-25
- [FIGURE 3-6](#) SunVTS GUI 3-52
- [FIGURE 3-7](#) SunVTS Test Selection Panel 3-53
- [FIGURE 4-1](#) Unlocking a Mounting Bracket 4-4
- [FIGURE 4-2](#) Location of the Mounting Bracket Release Buttons 4-4
- [FIGURE 4-3](#) Location of Top Cover Release Button 4-6
- [FIGURE 5-1](#) Releasing the PCI-Express Card Release Lever 5-2
- [FIGURE 5-2](#) Removing and Installing the PCI-Express Card 5-3
- [FIGURE 5-3](#) Removing the Fan Tray Assembly 5-4
- [FIGURE 5-4](#) Removing the Power Supply 5-6
- [FIGURE 5-5](#) Installing the Power Supply 5-7
- [FIGURE 5-6](#) Removing the Single-Drive Assembly 5-8

FIGURE 5-7	Installing the Single-Drive Assembly	5-9
FIGURE 5-8	Location of Drive Power and Data Connectors on the Motherboard	5-10
FIGURE 5-9	Removing the Dual-Drive Assembly	5-11
FIGURE 5-10	Installing the Dual-Drive Assembly	5-13
FIGURE 5-11	DIMM Locations	5-15
FIGURE 5-12	Removing the Clock Battery From the Motherboard	5-22
FIGURE 5-13	Installing the Clock Battery on the Motherboard	5-23
FIGURE A-1	Field-Replaceable Units	A-2

Tables

TABLE 3-1	Diagnostic Flowchart Actions	3–4
TABLE 3-2	Front and Rear Panel LEDs	3–10
TABLE 3-3	Power Supply LEDs	3–11
TABLE 3-4	Service-Related ALOM CMT Commands	3–14
TABLE 3-5	ALOM CMT Parameters Used for POST Configuration	3–23
TABLE 3-6	ALOM CMT Parameters and POST Modes	3–26
TABLE 3-7	ASR Commands	3–47
TABLE 3-8	Useful SunVTS Tests to Run on This Server	3–53
TABLE 5-1	DIMM Names and Socket Numbers	5–15
TABLE A-1	Server FRU List	A–3

Preface

The *Sun Fire T1000 Server Service Manual* provides information to aid in troubleshooting problems with and replacing components within the Sun Fire™ T1000 server.

This manual is written for technicians, service personnel, and system administrators who service and repair computer systems. The person qualified to use this manual:

- Can open a system chassis, identify, and replace internal components
- Understands the Solaris™ Operating System and the command-line interface
- Has superuser privileges for the system being serviced
- Understands typical hardware troubleshooting tasks

How This Book Is Organized

This guide is organized into the following chapters:

[Chapter 1](#) describes the safety precautions of the server.

[Chapter 2](#) describes the main features of the server.

[Chapter 3](#) describes the diagnostics that are available for monitoring and troubleshooting the server.

[Chapter 4](#) describes how to prepare for servicing the server.

[Chapter 5](#) describes how to remove and replace the field-replaceable units (FRUs) within the server.

[Chapter 6](#) describes how to finish up the servicing of the server.

[Appendix A](#) lists the field-replaceable components in the server.

Using UNIX Commands

This document might not contain information about basic UNIX® commands and procedures such as shutting down the system, booting the system, and configuring devices. Refer to the following for this information:

- Software documentation that you received with your system
- Solaris™ Operating System documentation, which is at: <http://docs.sun.com>

Typographic Conventions

Typeface*	Meaning	Examples
AaBbCc123	The names of commands, files, and directories; on-screen computer output	Edit your <code>.login</code> file. Use <code>ls -a</code> to list all files. % You have mail.
AaBbCc123	What you type, when contrasted with on-screen computer output	% su Password:
<i>AaBbCc123</i>	Book titles, new words or terms, words to be emphasized. Replace command-line variables with real names or values.	Read Chapter 6 in the <i>User's Guide</i> . These are called <i>class</i> options. You <i>must</i> be superuser to do this. To delete a file, type <code>rm filename</code> .

* The settings on your browser might differ from these settings.

Shell Prompts

Shell	Prompt
C shell	<i>machine-name%</i>
C shell superuser	<i>machine-name#</i>
Bourne shell and Korn shell	\$
Bourne shell and Korn shell superuser	#

Sun Fire T1000 Server Documentation

You can view and print the following documents from the Sun documentation web site at <http://www.sun.com/documentation>

Title	Description	Part Number
<i>Sun Fire T1000 Server Site Planning Guide</i>	Site planning information for the server.	819-3749
<i>Sun Fire T1000 Server Product Notes</i>	Late-breaking information about the server. The latest notes are posted at: http://www.sun.com/documentation	819-3246
<i>Sun Fire T1000 Server Getting Started Guide</i>	Information about where to find documentation to get your system installed and running quickly.	819-3244
<i>Sun Fire T1000 Server Overview</i>	Provides an overview of the features of this server.	819-3245
<i>Sun Fire T1000 Server Installation Guide</i>	Detailed rackmounting, cabling, power-on, and configuration information.	819-3247
<i>Sun Fire T1000 Server Administration Guide</i>	How to perform administrative tasks that are specific to this server.	819-3249
<i>Advanced Lights Out Management (ALOM) CMT Guide</i>	How to use the Advanced Lights Out Manager (ALOM) CMT software on this server.	819-3250 (version 1.1) 819-6672 (version 1.2)
<i>Sun Fire T1000 Server Safety and Compliance Guide</i>	Provides safety and compliance information that is specific to this server.	819-6674

Additional Service Related Information

In addition to this service manual, the following resources are available to help you keep your server running optimally:

- **Product Notes** – The *Sun Fire T1000 Server Product Notes* (819-3246) contain late-breaking information about the system including required software patches, updated hardware and compatibility information, and solutions to known issues. The product notes are available online at:
<http://www.sun.com/documentation>

- **Release Notes** – The Solaris OS release notes contain important information about the Solaris OS. The release notes are available online at:
<http://www.sun.com/documentation>
- **SunSolveSM Online** – Provides a collection of support resources. Depending on the level of your service contract, you have access to Sun patches, the Sun System Handbook, the SunSolveTM knowledge base, the Sun Support Forum, and additional documents, bulletins, and related links. Access this site at:
<http://sunsolve.sun.com>
- **Predictive Self-Healing Knowledge Database** – You can access the knowledge article corresponding to a self-healing message by taking the Sun Message Identifier (SUNW-MSG-ID) and entering it into the field on this page:
<http://www.sun.com/msg>

Documentation, Support, and Training

Sun Function	URL
Documentation	http://www.sun.com/documentation/
Support	http://www.sun.com/support/
Training	http://www.sun.com/training/

Third-Party Web Sites

Sun is not responsible for the availability of third-party web sites mentioned in this document. Sun does not endorse and is not responsible or liable for any content, advertising, products, or other materials that are available on or through such sites or resources. Sun will not be responsible or liable for any actual or alleged damage or loss caused by or in connection with the use of or reliance on any such content, goods, or services that are available on or through such sites or resources.

Sun Welcomes Your Comments

Sun is interested in improving its documentation and welcomes your comments and suggestions. You can submit your comments by going to:

<http://www.sun.com/hwdocs/feedback>

Please include the title and part number of your document with your feedback:

Sun Fire T1000 Server Service Manual, part number 819-3248-13

Safety Information

This chapter provides important safety information for servicing the server.

The following topics are covered:

- [Section 1.1, “Safety Information” on page 1-1](#)
- [Section 1.2, “Safety Symbols” on page 1-1](#)
- [Section 1.3, “Electrostatic Discharge Safety” on page 1-2](#)

1.1 Safety Information

This section describes safety information you need to know prior to removing or installing parts in the server.

For your protection, observe the following safety precautions when setting up your equipment:

- Follow all Sun standard cautions, warnings, and instructions marked on the equipment and described in *Important Safety Information for Sun Hardware Systems*, 816-7190.
- Ensure that the voltage and frequency of your power source match the voltage and frequency inscribed on the equipment’s electrical rating label.
- Follow the electrostatic discharge safety practices as described in this [Section 1.3, “Electrostatic Discharge Safety” on page 1-2](#).

1.2 Safety Symbols

The following symbols might appear in this document. Note their meanings:



Caution – There is a risk of personal injury and equipment damage. To avoid personal injury and equipment damage, follow the instructions.



Caution – Hot surface. Avoid contact. Surfaces are hot and might cause personal injury if touched.



Caution – Hazardous voltages are present. To reduce the risk of electric shock and danger to personal health, follow the instructions.

1.3 Electrostatic Discharge Safety

Electrostatic discharge (ESD) sensitive devices, such as the motherboard, PCI cards, hard drives, and memory cards require special handling.



Caution – The boards and hard drives contain electronic components that are extremely sensitive to static electricity. Ordinary amounts of static electricity from clothing or the work environment can destroy components. Do not touch the components along their connector edges.

1.3.1 Using an Antistatic Wrist Strap

Wear an antistatic wrist strap and use an antistatic mat when handling components such as drive assemblies, boards, or cards. When servicing or removing server components, attach an antistatic strap to your wrist and then to a metal area on the chassis. Do this after you disconnect the power cords from the server. Following this practice equalizes the electrical potentials between you and the server.

1.3.2 Using an Antistatic Mat

Place ESD-sensitive components such as the motherboard, memory, and other PCB cards on an antistatic mat.

Server Overview

This chapter provides an overview of the server. Topics include:

- [Section 2.1, “Server Overview” on page 2-1](#)
- [Section 2.2, “Obtaining the Chassis Serial Number” on page 2-3](#)

2.1 Server Overview

The server is a high-performance, entry-level server that is highly scalable and very reliable ([FIGURE 2-1](#)).




FIGURE 2-1 Server

FIGURE 2-2 shows the major components in the server, and FIGURE 2-3 and FIGURE 2-4 show the front and rear panels of the server.




FIGURE 2-2 Server Components




FIGURE 2-3 Server Front Panel




FIGURE 2-4 Server Rear Panel

2.2 Obtaining the Chassis Serial Number

To obtain support for your system, you need your chassis serial number. On the server, the chassis serial number is located on a sticker that is on the front of the server and another sticker at the rear of the server, below the AC power connector. You can also run the ALOM CMT `showplatform` command to obtain the chassis serial number.

Example:

```
sc> showplatform
SUNW,Sun-Fire-T1000
Chassis Serial Number: 0529AP000882
Domain Status
-----
S0 OS Standby
sc>
```


Server Diagnostics

This chapter describes the diagnostics that are available for monitoring and troubleshooting the server. This chapter does not provide detailed troubleshooting procedures, but instead describes the server diagnostics facilities and how to use them.

This chapter is intended for technicians, service personnel, and system administrators who service and repair computer systems.

The following topics are covered:

- [Section 3.1, “Overview of Server Diagnostics” on page 3-1](#)
- [Section 3.2, “Using LEDs to Identify the State of Devices” on page 3-8](#)
- [Section 3.3, “Using ALOM CMT for Diagnosis and Repair Verification” on page 3-11](#)
- [Section 3.4, “Running POST” on page 3-22](#)
- [Section 3.5, “Using the Solaris Predictive Self-Healing Feature” on page 3-39](#)
- [Section 3.6, “Collecting Information From Solaris OS Files and Commands” on page 3-45](#)
- [Section 3.7, “Managing Components With Automatic System Recovery Commands” on page 3-46](#)
- [Section 3.8, “Exercising the System With SunVTS” on page 3-49](#)

3.1 Overview of Server Diagnostics

There are a variety of diagnostic tools, commands, and indicators you can use to troubleshoot a server.

- **LEDs** – Provide a quick visual notification of the status of the server and of some of the FRUs.

- **ALOM CMT firmware** – Is the system firmware that runs on the system controller. In addition to providing the interface between the hardware and OS, ALOM CMT also tracks and reports the health of key server components. ALOM CMT works closely with POST and Solaris Predictive Self-Healing technology to keep the system up and running even when there is a faulty component.
- **Power-on self-test (POST)** – Performs diagnostics on system components upon system reset to ensure the integrity of those components. POST is configurable and works with ALOM CMT to take faulty components offline if needed and blacklist them in the *asr-db*.
- **Solaris OS Predictive Self-Healing (PSH)** – This technology continuously monitors the health of the CPU and memory, and works with ALOM CMT to take a faulty component offline if needed. The Predictive Self-Healing technology enables systems to accurately predict component failures and mitigate many serious problems before they occur.
- **Log files and console messages** – Provide the standard Solaris OS log files and investigative commands that can be accessed and displayed on the device of your choice.
- **SunVTS™** – An application that exercises the system, provides hardware validation, and discloses possible faulty components with recommendations for repair.


The LEDs, ALOM CMT, Solaris OS PSH, and many of the log files and console messages are integrated. For example, a fault detected by the Solaris PSH software displays the fault, logs it, passes information to ALOM CMT where it is logged, and depending on the fault, might illuminate one or more LEDs.

The diagnostic flow chart in [FIGURE 3-1](#) and [TABLE 3-1](#) describes an approach for using the server diagnostics to identify a faulty field-replaceable unit (FRU). The diagnostics you use, and the order in which you use them, depend on the nature of the problem you are troubleshooting, so you might perform some actions and not others.

The flow chart assumes that you have already performed some troubleshooting such as verification of proper installation and visual inspection of cables and power, and possibly performed a reset of the server (refer to the *Sun Fire T1000 Server Installation Guide* and *Sun Fire T1000 Server Administration Guide* for details).

[FIGURE 3-1](#) is a flow chart of the diagnostics available to troubleshoot faulty hardware. [TABLE 3-1](#) has more information about each diagnostic in this chapter.

Note – POST is configured with ALOM CMT configuration variables ([TABLE 3-6](#)). If `diag_level` is set to `max` (`diag_level=max`), POST reports *all* detected FRUs including memory devices with errors correctable by Predictive Self-Healing (PSH). Thus, not all memory devices detected by POST need to be replaced. See [Section 3.4.5, “Correctable Errors Detected by POST”](#) on page 3-35.



Numbers in this flow chart correspond to the Action numbers in Table 2-1.

FIGURE 3-1 Diagnostic Flowchart

TABLE 3-1 Diagnostic Flowchart Actions

Action No.	Diagnostic Action	Resulting Action	For more information, see these sections
1.	Check Power OK and AC OK LEDs on the server.	<p>The Power OK LED is located on the front and rear of the chassis.</p> <p>The AC OK LED is located on the rear of the server on each power supply.</p> <p>If these LEDs are not on, check the power source and power connections to the server.</p>	Section 3.2, “Using LEDs to Identify the State of Devices” on page 3-8
2.	Run the ALOM CMT <code>showfaults</code> command to check for faults.	<p>The <code>showfaults</code> command displays the following kinds of faults:</p> <ul style="list-style-type: none">• Environmental faults• Solaris Predictive Self-Healing (PSH) detected faults• POST detected faults <p>Faulty FRUs are identified in fault messages using the FRU name. For a list of FRU names, see Appendix A.</p>	Section 3.3.2, “Running the <code>showfaults</code> Command” on page 3-16
3.	Check the Solaris log files for fault information.	<p>The Solaris message buffer and log files record system events and provide information about faults.</p> <ul style="list-style-type: none">• If system messages indicate a faulty device, replace the FRU.• To obtain more diagnostic information, go to Action No. 4.	Section 3.6, “Collecting Information From Solaris OS Files and Commands” on page 3-45 Chapter 5
4.	Run SunVTS.	<p>SunVTS is an application you can run to exercise and diagnose FRUs. To run SunVTS, the server must be running the Solaris OS.</p> <ul style="list-style-type: none">• If SunVTS reports a faulty device replace the FRU.• If SunVTS does not report a faulty device, go to Action No. 5.	Section 3.8, “Exercising the System With SunVTS” on page 3-49 Chapter 5

TABLE 3-1 Diagnostic Flowchart Actions (*Continued*)

Action No.	Diagnostic Action	Resulting Action	For more information, see these sections
5.	Run POST.	<p>POST performs basic tests of the server components and reports faulty FRUs.</p> <p>Note - <code>diag_level=min</code> is the default ALOM CMT setting, which tests devices required to boot the server. Use <code>diag_level=max</code> for troubleshooting and hardware replacement.</p> <ul style="list-style-type: none"> • If POST indicates a faulty FRU while <code>diag_level=min</code>, replace the FRU. • If POST indicates a faulty memory device while <code>diag_level=max</code>, the detected errors might be correctable by PSH after the server boots. • If POST does not indicate a faulty FRU, go to Action No. 9. 	<p>Section 3.4, “Running POST” on page 3-22</p> <p>TABLE 3-5, TABLE 3-6</p> <p>Chapter 5</p> <p>Section 3.4.5, “Correctable Errors Detected by POST” on page 3-35</p>
6.	Determine if the fault is an environmental fault.	<p>If the fault listed by the <code>showfaults</code> command displays a temperature or voltage fault, then the fault is an environmental fault. Environmental faults can be caused by faulty FRUs (power supply or fan tray) or by environmental conditions such as when computer room ambient temperature is too high, or the server airflow is blocked. When the environmental condition is corrected, the fault will automatically clear. You can also use the fault LEDs on the server to identify the faulty FRU (fan tray or power supply).</p>	<p>Section 3.3.2, “Running the <code>showfaults</code> Command” on page 3-16</p> <p>Chapter 5, Section , “Replacing Field-Replaceable Units” on page 5-1</p> <p>Section 3.2, “Using LEDs to Identify the State of Devices” on page 3-8</p>

TABLE 3-1 Diagnostic Flowchart Actions (*Continued*)

Action No.	Diagnostic Action	Resulting Action	For more information, see these sections
7.	Determine if the fault was detected by PSH.	<p>If the fault message displays the following text, the fault was detected by the Solaris Predictive Self-Healing software:</p> <p>Host detected fault</p> <p>If the fault is a PSH detected fault, identify the faulty FRU from the fault message and replace the faulty FRU.</p> <p>After the FRU is replaced, perform the procedure to clear PSH detected faults.</p>	<p>Section 3.5, “Using the Solaris Predictive Self-Healing Feature” on page 3-39</p> <p>Chapter 5, Section , “Replacing Field-Replaceable Units” on page 5-1</p> <p>Section 3.5.2, “Clearing PSH Detected Faults” on page 3-44</p>
8.	Determine if the fault was detected by POST.	<p>POST performs basic tests of the server components and reports faulty FRUs. When POST detects a faulty FRU, it logs the fault and if possible, takes the FRU offline. POST detected FRUs display the following text in the fault message:</p> <p><i>FRU_name</i> deemed faulty and disabled</p> <p>In this case, replace the FRU and run the procedure to clear POST detected faults.</p>	<p>Section 3.4, “Running POST” on page 3-22</p> <p>Chapter 5, Section , “Replacing Field-Replaceable Units” on page 5-1</p> <p>Section 3.4.6, “Clearing POST Detected Faults” on page 3-38</p>
9.	Contact technical support.	<p>The majority of hardware faults are detected by the server’s diagnostics. In rare cases a problem might require additional troubleshooting. If you are unable to determine the cause of the problem, contact technical support.</p>	<p>Section 2.2, “Obtaining the Chassis Serial Number” on page 2-3</p>

3.1.1 Memory Configuration and Fault Handling

A variety of features play a role in how the memory subsystem is configured and how memory faults are handled. Understanding the underlying features helps you identify and repair memory problems. This section describes how the memory is configured and how the server deals with memory faults.

3.1.1.1 Memory Configuration

In the server memory, there are eight slots that hold DDR-2 memory DIMMs in the following DIMM sizes:

- 512 MB (maximum of 4 GB)
- 1 GB (maximum of 8 GB)
- 2GB (maximum of 16 GB)

All DIMMS installed must be the same size, and DIMMs must be added four at a time. In addition, Rank 0 memory must be fully populated for the server to function.

See [Section 5.5.2, “Installing DIMMs” on page 5-16](#), for instructions about adding memory to the server.

3.1.1.2 Memory Fault Handling

The server uses advanced ECC technology, also called chipkill, that corrects up to 4-bits in error on nibble boundaries, as long as the bits are all in the same DRAM. If a DRAM fails, the DIMM continues to function.

The following server features independently manage memory faults:

- **POST** – Based on ALOM CMT configuration variables, POST runs when the server is powered on. In normal operation, the default configuration of POST (`diag_level=min`), provides a check to ensure the server will boot. Normal operation applies to any boot of the server not intended to test power-on errors, hardware upgrades, or repairs. Once the Solaris OS is running, PSH provides run-time diagnosis of faults.

When a memory fault is detected, POST displays the fault with the device name of the faulty DIMMS, logs the fault, and disables the faulty DIMMs by placing them in the ASR blacklist. For a given memory fault, POST disables half of the physical memory in the system. When this offlining process occurs in normal operation, you must replace the faulty DIMMs based on the fault message and enable the disabled DIMMs with the ALOM CMT `enablecomponent` command.

In other than normal operation, POST can be configured to run various levels of testing (see [TABLE 3-5](#) and [TABLE 3-6](#)) and can thoroughly test the memory subsystem based on the purpose of the test. However, with thorough testing enabled (`diag_level=max`), POST finds faults and offlines memory devices with errors that could be correctable with PSH. Thus, not all memory devices detected and offlined by POST need to be replaced. See [Section 3.4.5, “Correctable Errors Detected by POST” on page 3-35](#).

- **Solaris Predictive Self-Healing (PSH) technology** – A feature of the Solaris OS, uses the fault manager daemon (`fmfd`) to watch for various kinds of faults. When a fault occurs, the fault is assigned a unique fault ID (UUID), and logged. PSH reports the fault and provides a recommended proactive replacement for the DIMMs associated with the fault.

3.1.1.3 Troubleshooting Memory Faults

If you suspect that the server has a memory problem, follow the flow chart (see [TABLE 3-1](#)). Run the ALOM CMT `showfaults` command. The `showfaults` command lists memory faults and lists the specific DIMMs that are associated with the fault. Once you identify which DIMMs to replace, see [Chapter 5](#) for DIMM removal and replacement instructions. It is important that you perform the instructions in that chapter to clear the faults and enable the replaced DIMMs.

3.2 Using LEDs to Identify the State of Devices

The server provides the following groups of LEDs:

- Front and rear panel LEDs ([FIGURE 3-2](#), [FIGURE 3-3](#), and [TABLE 3-2](#))
- Power supply LEDs ([FIGURE 3-3](#) and [TABLE 3-3](#))

These LEDs provide a quick visual check of the state of the system.




FIGURE 3-2 LEDs on the Server Front Panel




FIGURE 3-3 LEDs on the Server Rear Panel

3.2.1 Front and Rear Panel LEDs

Two LEDs and one LED/button are located in the upper left corner of the front panel (TABLE 3-2). The LEDs are also provided on the rear panel.

TABLE 3-2 Front and Rear Panel LEDs

LED	Location	Color	Description
Locator LED/button	Front and rear panels	White	Enables you to identify a particular server. Activate the LED using one of the following methods: <ul style="list-style-type: none">• Issuing the <code>setlocator on</code> or <code>off</code> command.• Pressing the button to toggle the indicator on or off. This LED provides the following indications: <ul style="list-style-type: none">• Off – Normal operating state.• Fast blink – The server received a signal as a result of one of the preceding methods and is indicating <i>here I am</i>— that it is operational.
Service Required LED	Front and rear panels	Yellow	If on, indicates that service is required. The ALOM CMT <code>showfaults</code> command will indicate any faults causing this indicator to light.
Power OK LED	Front and rear panels	Green	The LED provides the following indications: <ul style="list-style-type: none">• Off – Indicates that the system is unavailable. Either it has no power or ALOM CMT is not running.• Steady on – Indicates that the system is powered on and is running in its normal operating state. No service actions are required.• Standby blink – Indicates the system is running at a minimum level in standby and is ready to be quickly returned to full function. The service processor is running.• Slow blink – Indicates that a normal transitory activity is taking place. Server diagnostics could be running, or the system might be powering on.
Power On/Off button	Front panel	N/A	Turns the server on and off.
Ethernet Link Activity LEDs	Rear panel	Green	These LEDs indicate that there is activity on the associated nets.
Ethernet Link LEDs	Rear panel	Yellow	Indicates that the server is linked to the associated nets.
SC Network Management Activity LED	Rear panel	Yellow	Indicates that there is activity on the SC Network Management port.
SC Network Management Link LED	Rear panel	Green	Indicates that the server is linked to the SC network management port.

3.2.2 Power Supply LEDs

The power supply LEDs (TABLE 3-3) are located on the back of the power supply.

TABLE 3-3 Power Supply LEDs

Name	Color	Description
Fault	Amber	<ul style="list-style-type: none">• On – Power supply has detected a failure.• Off – Normal operation.
DC OK	Green	<ul style="list-style-type: none">• On – Normal operation. DC output voltage is within normal limits.• Off – Power is off.
AC OK	Green	<ul style="list-style-type: none">• On – Normal operation. Input power is within normal limits.• Off – No input voltage, or input voltage is below limits.

3.3 Using ALOM CMT for Diagnosis and Repair Verification

The Sun Advanced Lights Out Management (ALOM) CMT is a system controller in the server that enables you to remotely manage and administer your server.

ALOM CMT enables you to remotely run diagnostics, such as power-on self-test (POST), that would otherwise require physical proximity to the server's serial port. You can also configure ALOM CMT to send email alerts of hardware failures, hardware warnings, and other events related to the server or to ALOM CMT.

The ALOM CMT circuitry runs independently of the server, using the server's standby power. Therefore, ALOM CMT firmware and software continue to function when the server operating system goes offline or when the server is powered off.

Note – Refer to the *Advanced Lights Out Management (ALOM) CMT Guide* for comprehensive ALOM CMT information.

Faults detected by ALOM CMT, POST, and the Solaris Predictive Self-Healing (PSH) technology are forwarded to ALOM CMT for fault handling (FIGURE 3-4).

In the event of a system fault, ALOM CMT ensures that the Service Required LED is lit, FRU ID PROMs are updated, the fault is logged, and alerts are displayed. Faulty FRUs are identified in fault messages using the FRU name. For a list of FRU names, see [Appendix A](#).




FIGURE 3-4 ALOM CMT Fault Management

ALOM CMT sends alerts to all ALOM CMT users that are logged in, sending the alert through email to a configured email address, and writing the event to the ALOM CMT event log.

ALOM CMT can detect when a fault is no longer present and clears the fault in several ways:

- **Fault recovery** – The system automatically detects that the fault condition is no longer present. ALOM CMT extinguishes the Service Required LED and updates the FRU's PROM, indicating that the fault is no longer present.
- **Fault repair** – The fault has been repaired by human intervention. In most cases, ALOM CMT detects the repair and extinguishes the Service Required LED. If ALOM CMT does not perform these actions, you must perform these tasks manually using the `clearfault` or `enablecomponent` commands.

ALOM CMT can detect the removal of a FRU, in many cases even if the FRU is removed while ALOM CMT is powered off. This enables ALOM CMT to know that a fault, diagnosed to a specific FRU, has been repaired. The ALOM CMT `clearfault` command enables you to manually clear certain types of faults without a FRU replacement or if ALOM CMT was unable to automatically detect the FRU replacement.

Note – ALOM CMT does not automatically detect hard drive replacement.

Many environmental faults can automatically recover. A temperature that is exceeding a threshold might return to normal limits. An unplugged power supply can be plugged in, and so on. Recovery of environmental faults is automatically detected. Recovery events are reported using one of two forms:

- *fru at location is OK.*
- *sensor at location is within normal range.*

Environmental faults can be repaired through the removal of the faulty FRU. FRU removal is automatically detected by the environmental monitoring and all faults associated with the removed FRU are cleared. The message for that case, and the alert sent for all FRU removals is:

fru at location has been removed.

There is no ALOM CMT command to manually repair an environmental fault.

The Solaris Predictive Self-Healing technology does not monitor the hard drive for faults. As a result, ALOM CMT does not recognize hard drive faults, and will not light the fault LEDs on either the chassis or the hard drive itself. Use the Solaris message files to view hard drive faults. See [Section 3.6, “Collecting Information From Solaris OS Files and Commands”](#) on page 3-45.

3.3.1 Running ALOM CMT Service-Related Commands

This section describes the ALOM CMT commands that are commonly used for service-related activities.

3.3.1.1 Connecting to ALOM

Before you can run ALOM CMT commands, you must connect to the ALOM. There are several ways to connect to the system controller:

- Connect an ASCII terminal directly to the serial management port.
- Use either the `telnet` or the `ssh` command to connect to ALOM CMT through an Ethernet connection on the network management port. ALOM CMT can be configured for either the `telnet` or the `ssh` command, but not both.

Note – Refer to the *Advanced Lights Out Management (ALOM) CMT Guide* for instructions on configuring and connecting to ALOM.

3.3.1.2 Switching Between the System Console and ALOM

- To switch from the console output to the ALOM CMT `sc>` prompt, type `#.` (Hash-Period). Note that this command is user-configurable. Refer to the *Advanced Lights Out Management (ALOM) CMT Guide* for more information.
- To switch from the `sc>` prompt to the console, type `console`.

3.3.1.3 Service-Related ALOM CMT Commands

[TABLE 3-4](#) describes the typical ALOM CMT commands for servicing the server. For descriptions of all ALOM CMT commands, issue the `help` command or refer to the *Advanced Lights Out Management (ALOM) CMT Guide*.

TABLE 3-4 Service-Related ALOM CMT Commands

ALOM CMT Command	Description
<code>help [command]</code>	Displays a list of all ALOM CMT commands with syntax and descriptions. Specifying a command name as an option displays help for that command.
<code>break [-y][-c]</code>	Takes the host server from the OS to either <code>kmdb</code> or OpenBoot™ PROM (equivalent to a Stop-A), depending on the mode Solaris software was booted. The <code>-y</code> option skips the confirmation question. The <code>-c</code> option executes a <code>console</code> command after completion of the <code>break</code> command.
<code>clearfault UUID</code>	Manually clears host-detected faults. The <code>UUID</code> is the unique fault ID of the fault to be cleared.
<code>console [-f]</code>	Connects you to the host system. The <code>-f</code> option forces the console to have read and write capabilities.
<code>consolehistory [-b lines -e lines -v] [-g lines] [boot run]</code>	Displays the contents of the system's console buffer. The following options enable you to specify how the output is displayed: <ul style="list-style-type: none">• <code>-g lines</code> specifies the number of lines to display before pausing.• <code>-e lines</code> displays <i>n</i> lines from the end of the buffer.• <code>-b lines</code> displays <i>n</i> lines from beginning of buffer.• <code>-v</code> displays entire buffer.• <code>boot run</code> specifies the log to display (<code>run</code> is the default log).
<code>bootmode [normal reset_nvram bootscript=string]</code>	Enables control of the firmware during system initialization with the following options: <ul style="list-style-type: none">• <code>normal</code> is the default boot mode.• <code>reset_nvram</code> resets OpenBoot PROM parameters to their default values.• <code>bootscript=string</code> enables the passing of a string to the <code>boot</code> command.
<code>powercycle [-f]</code>	Performs a <code>poweroff</code> followed by <code>poweron</code> . The <code>-f</code> option forces an immediate <code>poweroff</code> , otherwise the command attempts a graceful shutdown.

TABLE 3-4 Service-Related ALOM CMT Commands (*Continued*)

ALOM CMT Command	Description
<code>poweroff [-y] [-f]</code>	Powers off the host server. The <code>-y</code> option enables you to skip the confirmation question. The <code>-f</code> option forces an immediate shutdown.
<code>poweron [-c]</code>	Powers on the host server. Using the <code>-c</code> option executes a <code>console</code> command after completion of the <code>poweron</code> command.
<code>reset [-y] [-c]</code>	Generates a hardware reset on the host server. The <code>-y</code> option enables you to skip the confirmation question. The <code>-c</code> option executes a <code>console</code> command after completion of the <code>reset</code> command.
<code>resetsc [-y]</code>	Reboots the system controller. The <code>-y</code> option enables you to skip the confirmation question.
<code>setkeyswitch [-y] normal stby diag locked</code>	Sets the virtual keyswitch. The <code>-y</code> option enables you to skip the confirmation question when setting the keyswitch to <code>stby</code> .
<code>setlocator [on off]</code>	Turns the Locator LED on the server on or off.
<code>showenvironment</code>	Displays the environmental status of the host server. This information includes system temperatures, power supply, front panel LED, hard drive, fan, voltage, and current sensor status. See Section 3.3.3, “Running the showenvironment Command” on page 3-17 .
<code>showfaults [-v]</code>	Displays current system faults. See Section 3.3.2, “Running the showfaults Command” on page 3-16 .
<code>showfru [-g lines] [-s -d] [FRU]</code>	Displays information about the FRUs in the server. <ul style="list-style-type: none"> • <code>-g lines</code> specifies the number of lines to display before pausing the output to the screen. • <code>-s</code> displays static information about system FRUs (defaults to all FRUs, unless one is specified). • <code>-d</code> displays dynamic information about system FRUs (defaults to all FRUs, unless one is specified). See Section 3.3.4, “Running the showfru Command” on page 3-19.
<code>showkeyswitch</code>	Displays the status of the virtual keyswitch.
<code>showlocator</code>	Displays the current state of the Locator LED as either on or off.
<code>showlogs [-b lines -e lines -v] [-g lines] [-p logtype[r p]]</code>	Displays the history of all events logged in the ALOM CMT event buffers (in RAM or the persistent buffers).
<code>showplatform [-v]</code>	Displays information about the host system’s hardware configuration, the system serial number, and whether the hardware is providing service.

Note – See [TABLE 3-7](#) for the ALOM CMT ASR commands.

3.3.2 Running the showfaults Command

The ALOM CMT `showfaults` command displays the following kinds of faults:

- Environmental faults – temperature or voltage problems that might be caused by faulty FRUs (a power supply or fan tray), or by room temperature or blocked air flow to the server.
- POST detected faults – faults on devices detected by the power-on self-test diagnostics.
- PSH detected faults – faults detected by the Solaris Predictive Self-Healing (PSH) technology

Use the `showfaults` command for the following reasons:

- To see if any faults have been passed to, or detected by ALOM.
 - To obtain the fault message ID (SUNW-MSG-ID) for PSH detected faults.
 - To verify that the replacement of a FRU has cleared the fault and not generated any additional faults.
- **At the `sc>` prompt, type the `showfaults` command.**

The following `showfaults` command examples show the different kinds of output from the `showfaults` command:

- Example of the `showfaults` command when no faults are present:

```
sc> showfaults
Last POST run: THU MAR 09 16:52:44 2006
POST status: Passed all devices

No failures found in System
```

- Example of the `showfaults` command displaying an environmental fault:

```
sc> showfaults -v
Last POST run: TUE FEB 07 18:51:02 2006
POST status: Passed all devices
  ID FRU          Fault
  0 IOBD          VOLTAGE_SENSOR at IOBD/V_+1V has exceeded
low warning threshold.
```


- Example showing a fault that was detected by POST. These kinds of faults are identified by the message `deemed faulty and disabled` and by a FRU name.

```
sc> showfaults -v
ID Time           FRU                               Fault
1 OCT 13 12:47:27 MB/CMP0/CH0/R1/D0 MB/CMP0/CH0/R1/D0 deemed
faulty and disabled
```

- Example showing a fault that was detected by the PSH technology. These kinds of faults are identified by the text `Host detected fault` and by a UUID.

```
sc> showfaults -v
ID Time           FRU                               Fault
0 SEP 09 11:09:26 MB/CMP0/CH0/R1/D0 Host detected fault, MSGID:
SUN4U-8000-2S  UUID: 7ee0e46b-ea64-6565-e684-e996963f7b86
```

3.3.3 Running the `showenvironment` Command

The `showenvironment` command displays a snapshot of the server's environmental status. This command displays system temperatures, hard disk drive status, power supply and fan status, front panel LED status, voltage and current sensors. The output uses a format similar to the Solaris OS command `prtdiag (1m)`.

- At the `sc>` prompt, type the `showenvironment` command.

The output differs according to your system's model and configuration. Example:

```
sc> showenvironment

===== Environmental Status =====

-----
System Temperatures (Temperatures in Celsius):
-----
Sensor           Status  Temp LowHard LowSoft LowWarn HighWarn HighSoft HighHard
-----
MB/T_AMB         OK      28   -10    -5     0     45     50     55
MB/CMP0/T_TCORE OK      50   -10    -5     0     85     90     95
MB/CMP0/T_BCORE OK      51   -10    -5     0     85     90     95
MB/IOB/T_CORE    OK      49   -10    -5     0     95    100    105

-----
System Indicator Status:
-----
```

SYS/LOCATE SYS/SERVICE SYS/ACT
OFF OFF ON

Fans (Speeds Revolution Per Minute):

Sensor	Status	Speed	Warn	Low
FT0/F0	OK	6762	2240	1920
FT0/F1	OK	6762	2240	1920
FT0/F2	OK	6762	2240	1920
FT0/F3	OK	6653	2240	1920

Voltage sensors (in Volts):

Sensor	Status	Voltage	LowSoft	LowWarn	HighWarn	HighSoft
MB/V_VCORE	OK	1.30	1.20	1.24	1.36	1.39
MB/V_VMEM	OK	1.79	1.69	1.72	1.87	1.90
MB/V_VTT	OK	0.89	0.84	0.86	0.93	0.95
MB/V_+1V2	OK	1.18	1.09	1.11	1.28	1.30
MB/V_+1V5	OK	1.49	1.36	1.39	1.60	1.63
MB/V_+2V5	OK	2.51	2.27	2.32	2.67	2.72
MB/V_+3V3	OK	3.29	3.06	3.10	3.49	3.53
MB/V_+5V	OK	5.02	4.55	4.65	5.35	5.45
MB/V_+12V	OK	12.25	10.92	11.16	12.84	13.08
MB/V_+3V3STBY	OK	3.33	3.13	3.16	3.53	3.59

System Load (in amps):

Sensor	Status	Load	Warn	Shutdown
MB/I_VCORE	OK	20.560	80.000	88.000
MB/I_VMEM	OK	8.160	60.000	66.000

Current sensors:

Sensor	Status
MB/BAT/V_BAT	OK

Power Supplies:

Supply	Status	Underspeed	Overtemp	Overvolt	Undervolt	Overcurrent
--------	--------	------------	----------	----------	-----------	-------------

PS0	OK	OFF	OFF	OFF	OFF	OFF
sc>						

Note – Some environmental information might not be available when the server is in Standby mode.

3.3.4 Running the showfru Command

The showfru command displays information about the FRUs in the server. Use this command to see information about an individual FRU, or for all the FRUs.

Note – By default, the output of the showfru command for all FRUs is very long.

- At the sc> prompt, enter the showfru command.

```

sc> showfru -s
FRU_PROM at MB/SEEPROM
SEGMENT: SD
/ManR
/ManR/UNIX_Timestamp32:      TUE OCT 18 21:17:55 2005
/ManR/Description:           ASSY,Sun-Fire-T1000,Motherboard
/ManR/Manufacture Location:  Sriracha,Chonburi,Thailand
/ManR/Sun Part No:           5017302
/ManR/Sun Serial No:         002989
/ManR/Vendor:                 Celestica
/ManR/Initial HW Dash Level: 03
/ManR/Initial HW Rev Level:  01
/ManR/Shortname:             T1000_MB
/SpecPartNo:                  885-0505-04

FRU_PROM at PS0/SEEPROM
SEGMENT: SD
/ManR
/ManR/UNIX_Timestamp32:      SUN JUL 31 19:45:13 2005
/ManR/Description:           PSU,300W,AC_INPUT,A207
/ManR/Manufacture Location:  Matamoros, Tamps, Mexico
/ManR/Sun Part No:           3001799
/ManR/Sun Serial No:         G00001
/ManR/Vendor:                 Tyco Electronics
/ManR/Initial HW Dash Level: 02
/ManR/Initial HW Rev Level:  01

```

```
/ManR/Shortname: PS
/SpecPartNo: 885-0407-02
```

```
FRU_PROM at MB/CMP0/CH0/R0/D0/SEEPROM
/SPD/Timestamp: MON OCT 03 12:00:00 2005
/SPD/Description: DDR2 SDRAM, 2048 MB
/SPD/Manufacture Location:
/SPD/Vendor: Infineon (formerly Siemens)
/SPD/Vendor Part No: 72T256220HR3.7A
/SPD/Vendor Serial No: d03fe27
```

```
FRU_PROM at MB/CMP0/CH0/R0/D1/SEEPROM
/SPD/Timestamp: MON OCT 03 12:00:00 2005
/SPD/Description: DDR2 SDRAM, 2048 MB
/SPD/Manufacture Location:
/SPD/Vendor: Infineon (formerly Siemens)
/SPD/Vendor Part No: 72T256220HR3.7A
/SPD/Vendor Serial No: d03f623
```

```
FRU_PROM at MB/CMP0/CH0/R1/D0/SEEPROM
/SPD/Timestamp: MON OCT 03 12:00:00 2005
/SPD/Description: DDR2 SDRAM, 2048 MB
/SPD/Manufacture Location:
/SPD/Vendor: Infineon (formerly Siemens)
/SPD/Vendor Part No: 72T256220HR3.7A
/SPD/Vendor Serial No: d03fc26
```

```
FRU_PROM at MB/CMP0/CH0/R1/D1/SEEPROM
/SPD/Timestamp: MON OCT 03 12:00:00 2005
/SPD/Description: DDR2 SDRAM, 2048 MB
/SPD/Manufacture Location:
/SPD/Vendor: Infineon (formerly Siemens)
/SPD/Vendor Part No: 72T256220HR3.7A
/SPD/Vendor Serial No: d03eb26
```

```
FRU_PROM at MB/CMP0/CH3/R0/D0/SEEPROM
/SPD/Timestamp: MON OCT 03 12:00:00 2005
/SPD/Description: DDR2 SDRAM, 2048 MB
/SPD/Manufacture Location:
/SPD/Vendor: Infineon (formerly Siemens)
/SPD/Vendor Part No: 72T256220HR3.7A
/SPD/Vendor Serial No: d03e620
```

```
FRU_PROM at MB/CMP0/CH3/R0/D1/SEEPROM
/SPD/Timestamp: MON OCT 03 12:00:00 2005
/SPD/Description: DDR2 SDRAM, 2048 MB
/SPD/Manufacture Location:
/SPD/Vendor: Infineon (formerly Siemens)
/SPD/Vendor Part No: 72T256220HR3.7A
/SPD/Vendor Serial No: d040920
```

```
FRU_PROM at MB/CMP0/CH3/R1/D0/SEEPROM
/SPD/Timestamp: MON OCT 03 12:00:00 2005
/SPD/Description: DDR2 SDRAM, 2048 MB
/SPD/Manufacture Location:
/SPD/Vendor: Infineon (formerly Siemens)
/SPD/Vendor Part No: 72T256220HR3.7A
/SPD/Vendor Serial No: d03ec27
```

```
FRU_PROM at MB/CMP0/CH3/R1/D1/SEEPROM
/SPD/Timestamp: MON OCT 03 12:00:00 2005
/SPD/Description: DDR2 SDRAM, 2048 MB
/SPD/Manufacture Location:
/SPD/Vendor: Infineon (formerly Siemens)
/SPD/Vendor Part No: 72T256220HR3.7A
/SPD/Vendor Serial No: d040924
```

```
sc>
```

3.4 Running POST

Power-on self-test (POST) is a group of PROM-based tests that run when the server is powered on or reset. POST checks the basic integrity of the critical hardware components in the server (CPU, memory, and I/O buses).

If POST detects a faulty component, the component is disabled automatically, preventing faulty hardware from potentially harming any software. If the system is capable of running without the disabled component, the system will boot when POST is complete. For example, if one of the processor cores is deemed faulty by POST, the core will be disabled, and the system will boot and run using the remaining cores.

In normal operation*, the default configuration of POST (`diag_level=min`), provides a sanity check to ensure the server will boot. Normal operation applies to any power on of the server not intended to test power-on errors, hardware upgrades, or repairs. Once the Solaris OS is running, PSH provides run time diagnosis of faults.

***Note** – Earlier versions of firmware have `max` as the default setting for the POST `diag_level` variable. To set the default to `min`, use the ALOM CMT command, **`setsc diag_level min`**

For validating hardware upgrades or repairs, configure POST to run in maximum mode (`diag_level=max`). Note that with maximum testing enabled, POST detects and offlines memory devices with errors that could be correctable by PSH. Thus, not all memory devices detected by POST need to be replaced. See [Section 3.4.5, “Correctable Errors Detected by POST”](#) on page 3-35.

Note – Devices can be manually enabled or disabled using ASR commands (see [Section 3.7, “Managing Components With Automatic System Recovery Commands”](#) on page 3-46).

3.4.1 Controlling How POST Runs

The server can be configured for normal, extensive, or no POST execution. You can also control the level of tests that run, the amount of POST output that is displayed, and which reset events trigger POST by using ALOM CMT variables.

[TABLE 3-5](#) lists the ALOM CMT variables used to configure POST and [FIGURE 3-5](#) shows how the variables work together.

Note – Use the ALOM CMT `setsc` command to set all the parameters in [TABLE 3-5](#) except `setkeyswitch`.

TABLE 3-5 ALOM CMT Parameters Used for POST Configuration

Parameter	Values	Description
setkeyswitch	normal	The system can power on and run POST (based on the other parameter settings). For details see TABLE 3-6 . This parameter overrides all other commands.
	diag	The system runs POST based on predetermined settings.
	stby	The system cannot power on.
	locked	The system can power on and run POST, but no flash updates can be made.
diag_mode	off	POST does not run.
	normal	Runs POST according to <code>diag_level</code> value.
	service	Runs POST with preset values for <code>diag_level</code> and <code>diag_verbosity</code> .
diag_level	min	If <code>diag_mode = normal</code> , runs minimum set of tests.
	max	If <code>diag_mode = normal</code> , runs all the minimum tests plus extensive CPU and memory tests.
diag_trigger	none	Does not run POST on reset.
	user_reset	Runs POST upon user initiated resets.
	power_on_reset	Only runs POST for the first power on. This option is the default.
	error_reset	Runs POST if fatal errors are detected.
	all_reset	Runs POST after any reset.
diag_verbosity	none	No POST output is displayed.

TABLE 3-5 ALOM CMT Parameters Used for POST Configuration (*Continued*)

Parameter	Values	Description
	min	POST output displays functional tests with a banner and pinwheel.
	normal	POST output displays all test and informational messages.
	max	POST displays all test, informational, and some debugging messages.




FIGURE 3-5 Flowchart of ALOM CMT Variables for POST Configuration

TABLE 3-6 shows combinations of ALOM CMT variables and associated POST modes.

TABLE 3-6 ALOM CMT Parameters and POST Modes

Parameter	Normal Diagnostic Mode (Default Settings)	No POST Execution	Diagnostic Service Mode	Keyswitch Diagnostic Preset Values
diag_mode	normal	off	service	normal
setkeyswitch*	normal	normal	normal	diag
diag_level\ [\]	min	n/a	max	max
diag_trigger	power-on-reset error-reset	none	all-resets	all-resets
diag_verbosity	normal	n/a	max	max
Description of POST execution	This is the default POST configuration. This configuration tests the system thoroughly, and suppresses some of the detailed POST output.	POST does not run, resulting in quick system initialization, but this is not a suggested configuration.	POST runs the full spectrum of tests with the maximum output displayed.	POST runs the full spectrum of tests with the maximum output displayed.

* The setkeyswitch parameter, when set to diag, overrides all the other ALOM CMT POST variables.

\ Earlier versions of firmware have max as the default setting for the POST diag_level variable. To set the default to min, use the ALOM CMT command, setsc diag_level min

3.4.2 Changing POST Parameters

1. Access the ALOM CMT `sc>` prompt:

At the console, issue the #. key sequence:

```
#.
```

2. Use the ALOM CMT `sc>` prompt to change the POST parameters.

Refer to TABLE 3-5 for a list of ALOM CMT POST parameters and their values.

The setkeyswitch parameter sets the virtual keyswitch, so it does not use the setsc command. For example, to change the POST parameters using the setkeyswitch command, enter the following:

```
sc> setkeyswitch diag
```

To change the POST parameters using the `setsc` command, you must first set the `setkeyswitch` parameter to `normal`, then you can change the POST parameters using the `setsc` command:

```
sc> setkeyswitch normal  
sc> setsc value
```

Example:

```
sc> setkeyswitch normal  
sc> setsc diag_mode service
```

3.4.3 Reasons to Run POST

You can use POST for basic hardware verification and diagnosis, and for troubleshooting as described in the following sections.

3.4.3.1 Verifying Hardware Functionality

POST tests critical hardware components to verify functionality before the system boots and accesses software. If POST detects an error, the faulty component is disabled automatically, preventing faulty hardware from potentially harming software.

In normal operation (`diag_level=min`), POST runs in minimum mode by default to test devices required to power on the server. Replace any devices POST detects as faulty in minimum mode.

Run POST in maximum mode (`diag_level=max`) for all power-on or error-generated resets, and to validate hardware upgrades or repairs. With maximum testing enabled, POST finds faults and offlines memory devices with errors that could be correctable by PSH. Check the POST-generated errors with the `showfaults -v` command to verify if memory devices detected by POST can be corrected by PSH or need to be replaced. See [Section 3.4.5, “Correctable Errors Detected by POST”](#) on page 3-35.

3.4.3.2 Diagnosing the System Hardware

You can use POST as an initial diagnostic tool for the system hardware. In this case, configure POST to run in maximum mode (`diag_mode=service, setkeyswitch=diag, diag_level=max`) for thorough test coverage and verbose output.

3.4.4 Running POST in Maximum Mode

This procedure describes how to run POST when you want maximum testing, as in the case when you are troubleshooting a server or verifying a hardware upgrade or repair.

1. **Switch from the system console prompt to the `sc>` prompt by issuing the `#.` escape sequence.**

```
ok #.  
sc>
```

2. **Set the virtual keyswitch to `diag` so that POST will run in Service mode.**

```
sc> setkeyswitch diag
```

3. **Reset the system so that POST runs.**

There are several ways to initiate a reset. The following example uses the `powercycle` command. For other methods, refer to the *Sun Fire T1000 Server Administration Guide*.

```
sc> powercycle  
Are you sure you want to powercycle the system [y/n]? y  
Powering host off at MON JAN 10 02:52:02 2000  
  
Waiting for host to Power Off; hit any key to abort.  
  
SC Alert: SC Request to Power Off Host.  
  
SC Alert: Host system has shut down.  
Powering host on at MON JAN 10 02:52:13 2000  
  
SC Alert: SC Request to Power On Host.
```

4. Switch to the system console to view the POST output:

```
sc> console
```

Example of POST output:

```
SC: Alert: Host system has reset1 Note: Some output omitted.
0:0>
0:0>@(#) ERIE Integrated POST 4.x.0.build_17 2005/08/30 11:25
      /export/common-source/firmware_re/ontario-
fireball_fio/build_17/post/Niagara/erie/integrated (firmware_re)
0:0>Copyright © 2005 Sun Microsystems, Inc. All rights reserved
      SUN PROPRIETARY/CONFIDENTIAL.
      Use is subject to license terms.
0:0>VBSC selecting POST IO Testing.
0:0>VBSC enabling threads: 1
0:0>VBSC setting verbosity level 3
0:0>Start Selftest.....
0:0>Init CPU
0:0>Master CPU Tests Basic.....
0:0>CPU =: 0
0:0>DMMU Registers Access
0:0>IMMU Registers Access
0:0>Init mmu regs
0:0>D-Cache RAM
0:0>DMMU TLB DATA RAM Access
0:0>DMMU TLB TAGS Access
0:0>DMMU CAM
0:0>IMMU TLB DATA RAM Access
0:0>IMMU TLB TAGS Access
0:0>IMMU CAM
0:0>Setup and Enable DMMU
0:0>Setup DMMU Miss Handler
```

```
0:0> Niagara, Version 2.0
0:0> Serial Number 00000098.00000820 = fffff238.6b4c60e9
0:0>Init JBUS Config Regs
0:0>IO-Bridge unit 1 init test
0:0>sys 200 MHz, CPU 1000 MHz, mem 200 MHz.
0:0>Integrated POST Testing
0:0>L2 Tests.....
0:0>Setup L2 Cache
0:0>L2 Cache Control = 00000000.00300000
0:0>Scrub and Setup L2 Cache
0:0>L2 Directory clear
0:0>L2 Scrub VD & UA
0:0>L2 Scrub Tags
0:0>Test Memory Basic.....
0:0>Probe and Setup Memory
0:0>INFO:4096MB at Memory Channel [0 3 ] Rank 0 Stack 0
0:0>INFO:4096MB at Memory Channel [0 3 ] Rank 0 Stack 1
0:0>INFO:No memory detected at Memory Channel [0 3 ] Rank 1 Stack 0
0:0>INFO:No memory detected at Memory Channel [0 3 ] Rank 1 Stack 1
0:0>
0:0>Data Bitwalk
0:0>L2 Scrub Data
0:0>L2 Enable
0:0> Testing Memory Channel 0 Rank 0 Stack 0
0:0> Testing Memory Channel 3 Rank 0 Stack 0
0:0> Testing Memory Channel 0 Rank 0 Stack 1
0:0> Testing Memory Channel 3 Rank 0 Stack 1
0:0>L2 Directory clear
0:0>L2 Scrub VD & UA
0:0>L2 Scrub Tags
0:0>L2 Disable
```

```
0:0>Address Bitwalk
0:0>  Testing Memory Channel 0 Rank 0 Stack 0
0:0>  Testing Memory Channel 3 Rank 0 Stack 0
0:0>  Testing Memory Channel 0 Rank 0 Stack 1
0:0>  Testing Memory Channel 3 Rank 0 Stack 1
0:0>Test Slave Threads Basic.....
0:0>Set Mailbox
0:0>Setup Final DMMU Entries
0:0>Post Image Region Scrub
0:0>Run POST from Memory
0:0>Verifying checksum on copied image.
0:0>The Memory's CHECKSUM value is ccle.
0:0>The Memory's Content Size value is 7b192.
0:0>Success...  Checksum on Memory Validated.
0:0>L2 Cache Ram Test
0:0>Enable L2 Cache
0:0>L2 Scrub Data
0:0>L2 Enable
0:0>CPU =: 0
0:0>CPU =: 0
0:0>Test slave strand registers...
0:0>Extended CPU Tests.....
0:0>Scrub Icache
0:0>Scrub Dcache
0:0>D-Cache Tags
0:0>I-Cache RAM Test
0:0>I-Cache Tag RAM
0:0>FPU Registers and Data Path
0:0>FPU Move Registers
0:0>FSR Read/Write
0:0>FPU Branch Instructions
```

```

0:0>Enable Icache
0:0>Enable Dcache
0:0>Scrub Memory.....
0:0>Scrub Memory
0:0>Scrub 00000000.00600000->00000001.00000000 on Memory Channel [ 0 3 ] Rank 0
Stack 0
0:0>Scrub 00000001.00000000->00000002.00000000 on Memory Channel [ 0 3 ] Rank 0
Stack 1
0:0>IMMU Functional
0:0>DMMU Functional
0:0>Extended Memory Tests.....
0:0>Print Mem Config
0:0>Caches : Icache is ON, Dcache is ON.
0:0>  Bank 0 4096MB : 00000000.00000000 -> 00000001.00000000.
0:0>  Bank 1 4096MB : 00000001.00000000 -> 00000002.00000000.
0:0>Block Mem Test
0:0>Test 6291456 bytes at 00000000.00600000 Memory Channel [ 0 3 ] Rank 0 Stack 0
0:0>.....
0:0>Test 6291456 bytes at 00000001.00000000 Memory Channel [ 0 3 ] Rank 0 Stack 1
0:0>.....
0:0>IO-Bridge Tests.....
0:0>IO-Bridge Quick Read
0:0>
0:0>-----
0:0>----- IO-Bridge Quick Read Only of CSR and ID -----
0:0>-----
0:0>fire 1 JBUSID 00000080.0f000000 =
0:0>
fc000002.e03dda23
0:0>-----
0:0>fire 1 JBUSCSR 00000080.0f410000 =
0:0>
00000ff5.13cb7000
0:0>-----

```



```

0:0>IO-Bridge unit 1 jbus perf test
0:0>IO-Bridge unit 1 int init test
0:0>IO-Bridge unit 1 msi init test
0:0>IO-Bridge unit 1 ilu init test
0:0>IO-Bridge unit 1 tlu init test
0:0>IO-Bridge unit 1 lpu init test
0:0>IO-Bridge unit 1 link train port B
0:0>IO-Bridge unit 1 interrupt test
0:0>IO-Bridge unit 1 Config MB bridges
0:0>Config port B, bus 2 dev 0 func 0, tag 5714 BRIDGE
0:0>Config port B, bus 3 dev 8 func 0, tag PCIX BRIDGE
0:0>IO-Bridge unit 1 PCI id test
0:0> INFO:10 count read passed for MB/IOB_PCIEb/BRIDGE! Last read
VID:1166|DID:103
0:0> INFO:10 count read passed for MB/IOB_PCIEb/BRIDGE/GBE! Last read
VID:14e4|DID:1648
0:0> INFO:10 count read passed for MB/IOB_PCIEb/BRIDGE/HBA! Last read
VID:1000|DID:50
0:0>Quick JBI Loopback Block Mem Test
0:0>Quick jbus loopback Test 262144 bytes at 00000000.00600000
0:0>INFO:
0:0> POST Passed all devices.
0:0>POST:Return to VBSC.
0:0>Master set ACK for vbosc runpost command and spin...

```

5. Perform further investigation if needed.

- If no faults were detected, the system will boot.
- If POST detects a faulty device, the fault is displayed and the fault information is passed to ALOM CMT for fault handling. Faulty FRUs are identified in fault messages using the FRU name. For a list of FRU names, see [Appendix A](#).

a. Interpret the POST messages:

POST error messages use the following syntax:

```
c:s > ERROR: TEST = failing-test
c:s > H/W under test = FRU
c:s > Repair Instructions: Replace items in order listed by H/W
under test above
c:s > MSG = test-error-message
c:s > END_ERROR
```

In this syntax, *c* = the core number and *s* = the strand number.

Warning and informational messages use the following syntax:

```
INFO or WARNING: message
```

The following example shows a POST error message.

```
.
.
.

0:0>Data Bitwalk
0:0>L2 Scrub Data
0:0>L2 Enable
0:0>Testing Memory Channel 0 Rank 0 Stack 0
0:0>Testing Memory Channel 3 Rank 0 Stack 0
0:0>Testing Memory Channel 0 Rank 1 Stack 0
.
.
.
0:0>ERROR: TEST = Data Bitwalk
0:0>H/W under test = MB/CMP0/CH0/R1/D0/S0 (J0701)
0:0>Repair Instructions: Replace items in order listed by 'H/W
under test' above.
0:0>MSG = Pin 3 failed on MB/CMP0/CH0/R1/D0/S0 (J0701)
0:0>END_ERROR

0:0>Testing Memory Channel 3 Rank 1 Stack 0
```

In this example, POST is reporting a memory error at DIMM location MB/CMP0/CH0/R1/D0 (J0701).

b. Run the `showfaults` command to obtain additional fault information.

The fault is captured by ALOM, where the fault is logged, the Service Required LED is lit, and the faulty component is disabled.

Example:

```
ok #.  
sc> showfaults -v  
      ID   Time                FRU                Fault  
      1 APR 24 12:47:27    MB/CMP0/CH0/R1/D0  MB/CMP0/CH0/R1/D0  
deemed faulty and disabled
```

In this example, MB/CMP0/CH0/R1/D0 is disabled. The system can boot using memory that was not disabled until the faulty component is replaced.

Note – You can use ASR commands to display and control disabled components. See [Section 3.7, “Managing Components With Automatic System Recovery Commands”](#) on page 3-46.

3.4.5 Correctable Errors Detected by POST

In maximum mode, POST detects and offlines memory devices with errors that could be correctable by PSH. Use the examples in this section to verify if the detected memory devices are correctable.

Note – For servers powered on in maximum mode without the intention of validating a hardware upgrade or repair, examine *all* faults detected by POST to verify if the errors can be corrected by Solaris PSH. See [Section 3.5, “Using the Solaris Predictive Self-Healing Feature”](#) on page 3-39.

When using maximum mode, if no faults are detected, return POST to minimum mode.

```
sc> setkeyswitch normal  
sc> setsc diag_mode normal  
sc> setsc diag_level min
```

3.4.5.1 Correctable Errors for Single DIMMs

If POST faults a single DIMM ([CODE EXAMPLE 3-1](#)) that was not part of a hardware upgrade or repair, it is likely that POST encountered a correctable error that can be handled by PSH.

CODE EXAMPLE 3-1 POST Fault for a Single DIMM

```
sc> showfaults -v
ID Time          FRU                               Fault
1 OCT 13 12:47:27 MB/CMP0/CH0/R0/D0 MB/CMP0/CH0/R0/D0 deemed
  faulty and disabled
```

In this case, reenable the DIMM and run POST in minimum mode as follows:

1. Reenable the DIMM.

```
sc> enablecomponent name-of-DIMM
```

2. Return POST to minimum mode.

```
sc> setkeyswitch normal
sc> setsc diag_mode normal
sc> setsc diag_level min
```

3. Reset the system so that POST runs.

There are several ways to initiate a reset. The following example uses the `powercycle` command. For other methods, refer to the *Sun Fire T1000 Server Administration Guide*.

```
sc> powercycle
Are you sure you want to powercycle the system [y/n]? y
Powering host off at MON JAN 10 02:52:02 2000

Waiting for host to Power Off; hit any key to abort.

SC Alert: SC Request to Power Off Host.

SC Alert: Host system has shut down.
Powering host on at MON JAN 10 02:52:13 2000

SC Alert: SC Request to Power On Host.
```

4. Replace the DIMM if POST continues to fault the device in minimum mode.

3.4.5.2 Determining When to Replace Detected Devices

Note – This section assumes faults are detected by POST in maximum mode.

If a detected device is part of a hardware upgrade or repair, or if POST detects multiple DIMMs ([CODE EXAMPLE 3-2](#)), replace the detected devices.

CODE EXAMPLE 3-2 POST Fault for Multiple DIMMs

```
sc> showfaults -v
ID Time          FRU                      Fault
1 OCT 13 12:47:27 MB/CMP0/CH0/R0/D0 MB/CMP0/CH0/R0/D0 deemed
  faulty and disabled
2 OCT 13 12:47:27 MB/CMP0/CH0/R0/D1 MB/CMP0/CH0/R0/D1 deemed
  faulty and disabled
```

Note – The previous example shows two DIMMs on the same channel/rank, which could be an uncorrectable error.

If the detected device is *not* a part of a hardware upgrade or repair, use the following list to examine and repair the fault:

1. If a detected device is not a DIMM, or if more than a single DIMM is detected, replace the detected devices.
2. If a detected device is a single DIMM and the same DIMM is also detected by PSH, replace the DIMM ([CODE EXAMPLE 3-3](#)).

CODE EXAMPLE 3-3 PSH and POST Faults on the Same DIMM

```
sc> showfaults -v
ID Time          FRU                      Fault
0 SEP 09 11:09:26 MB/CMP0/CH0/R0/D0 Host detected fault,
  MSGID:SUN4V-8000-DX  UUID: 7ee0e46b-ea64-6565-e684-e996963f7b86
1 OCT 13 12:47:27 MB/CMP0/CH0/R0/D0 MB/CMP0/CH0/R0/D0 deemed
  faulty and disabled
```

Note – The detected DIMM in the previous example must also be replaced because it exceeds the PSH page retire threshold.

3. If a device detected by POST is a single DIMM and the same DIMM is not detected by PSH, follow the procedure in [Section 3.4.5.1, “Correctable Errors for Single DIMMs”](#) on page 3-36.

After the detected devices are repaired or replaced, return POST to the default minimum level.

```
sc> setkeyswitch normal
sc> setsc diag_mode normal
sc> setsc diag_level min
```

3.4.6 Clearing POST Detected Faults

In most cases, when POST detects a faulty component, POST logs the fault and automatically takes the failed component out of operation by placing the component in the ASR blacklist (see [Section 3.7, “Managing Components With Automatic System Recovery Commands”](#) on page 3-46).

In most cases, after the faulty FRU is replaced, ALOM CMT detects the repair and extinguishes the Service Required LED. If ALOM CMT does not perform these actions, use the `enablecomponent` command to manually clear the fault and remove the component from the ASR blacklist. This procedure describes how to do this.

1. **After replacing a faulty FRU, at the ALOM CMT prompt use the `showfaults` command to identify POST detected faults.**

POST detected faults are distinguished from other kinds of faults by the text: `deemed faulty and disabled`, and no UUID number is reported.

Example:

```
sc> showfaults -v
  ID   Time                FRU                Fault
  1 APR 24 12:47:27    MB/CMP0/CH0/R1/D0  MB/CMP0/CH0/R1/D0
deemed faulty and disabled
```

- If no fault is reported, you do not need to do anything else. Do not perform the subsequent steps.
- If a fault is reported, perform [Step 2](#) through [Step 4](#).

2. Use the `enablecomponent` command to clear the fault and remove the component from the ASR blacklist.

Use the FRU name that was reported in the fault in the previous step.

Example:

```
sc> enablecomponent MB/CMP0/CH0/R1/D0
```

The fault is cleared and should not appear when you run the `showfaults` command. Additionally, if there are no other faults remaining, the Service Required LED should be extinguished.

3. Power cycle the server.

You must reboot the server for the `enablecomponent` command to take effect.

4. At the ALOM CMT prompt, use the `showfaults` command to verify that no faults are reported.

```
sc> showfaults
Last POST run: THU MAR 09 16:52:44 2006
POST status: Passed all devices

No failures found in System
```

3.5 Using the Solaris Predictive Self-Healing Feature

The Solaris Predictive Self-Healing (PSH) technology enables the server to diagnose problems while the Solaris OS is running, and mitigate many problems before they negatively affect operations.

The Solaris OS uses the fault manager daemon, `fmd(1M)`, which starts at boot time and runs in the background to monitor the system. If a component generates an error, the daemon handles the error by correlating the error with data from previous errors and other related information to diagnose the problem. Once diagnosed, the fault manager daemon assigns the problem a Universal Unique Identifier (UUID) that distinguishes the problem across any set of systems. When possible, the fault manager daemon initiates steps to self-heal the failed component and take the component offline. The daemon also logs the fault to the `syslogd` daemon and

provides a fault notification with a message ID (MSGID). You can use the message ID to get additional information about the problem from Sun's knowledge article database.

The Predictive Self-Healing technology covers the following server components:

- UltraSPARC® T1 multicore processor
- Memory
- I/O bus

The PSH console message provides the following information:

- Type
- Severity
- Description
- Automated response
- Impact
- Suggested action for system administrator

If the Solaris PSH facility detects a faulty component, use the `fmddump` command to identify the fault. Faulty FRUs are identified in fault messages using the FRU name. For a list of FRU names, see [Appendix A](#).

Note – Additional Predictive Self-Healing information is available at:
<http://www.sun.com/msg>

3.5.1 Identifying PSH Detected Faults

When a PSH fault is detected, a Solaris console message similar to the following is displayed:

```
SUNW-MSG-ID: SUN4V-8000-DX, TYPE: Fault, VER: 1, SEVERITY: Minor
EVENT-TIME: Wed Sep 14 10:09:46 EDT 2005
PLATFORM: SUNW,Sun-Fire-T200, CSN: -, HOSTNAME: wgs48-37
SOURCE: cpumem-diagnosis, REV: 1.5
EVENT-ID: f92e9fbe-735e-c218-cf87-9e1720a28004
DESC: The number of errors associated with this memory module has exceeded
acceptable levels. Refer to http://sun.com/msg/SUN4V-8000-DX for more
information.
AUTO-RESPONSE: Pages of memory associated with this memory module are being
removed from service as errors are reported.
IMPACT: Total system memory capacity will be reduced as pages are retired.
REC-ACTION: Schedule a repair procedure to replace the affected memory module.
Use fmddump -v -u <EVENT_ID> to identify the module.
```


The following is an example of the ALOM CMT alert for the same PSH diagnosed fault:

```
SC Alert: Host detected fault, MSGID: SUN4V-8000-DX
```

Note – The Service Required LED is also turns on for PSH diagnosed faults.

3.5.1.1 Using the `fmddump` Command to Identify Faults

The `fmddump` command displays the list of faults detected by the Solaris PSH facility and identifies the faulty FRU for a particular `EVENT_ID` (UUID). Do not use `fmddump` to verify a FRU replacement has cleared a fault because the output of `fmddump` is the same after the FRU has been replaced. Use the `fmadm faulty` command to verify the fault has cleared.

Note – Faults detected by the Solaris PSH facility are also reported through ALOM CMT alerts. In addition to the PSH `fmddump` command, the ALOM CMT `showfaults` command provides information about faults and displays fault UUIDs. See [Section 3.3.2, “Running the showfaults Command” on page 3-16](#).

1. Check the event log using the `fmddump` command with `-v` for verbose output:

```
# fmddump -v
TIME                UUID                                SUNW-MSG-ID
Sep 14 10:09:46.2234 f92e9fbe-735e-c218-cf87-9e1720a28004 SUN4V-8000-DX
  95%  fault.memory.dimm
      FRU: mem:///component=MB/CMP0/CH0:R0/D0/J0601
      rsrc: mem:///component=MB/CMP0/CH0:R0/D0/J0601
```

In this example, a fault is displayed, indicating the following details:

- Date and time of the fault (Sep 14 10:09)
- Universal Unique Identifier (UUID) that is unique for every fault (f92e9fbe-735e-c218-cf87-9e1720a28004)
- Sun message identifier (SUN4V-8000-DX) that can be used to obtain additional fault information
- Faulted FRU (FRU: mem:///component=MB/CMP0/CH0:R0/D0/J0601), that in this example MB is identified as the DIMM at R0/D0 (J0601)

Note – `fmddump` displays the PSH event log. Entries remain in the log after the fault has been repaired.

2. Use the Sun message ID to obtain more information about this type of fault.
 - a. In a browser, go to the Predictive Self-Healing Knowledge Article web site:
<http://www.sun.com/msg>

- b. Obtain the message ID from the console output or the ALOM CMT showfaults command.
- c. **Enter the message ID in the SUNW-MSG-ID field, and click Lookup.**

In this example, the message ID SUN4V-8000-DX returns the following information for corrective action:

```

Article for Message ID:   SUN4V-8000-DX
Correctable memory errors exceeded acceptable levels
Type
    Fault
Severity
    Major
Description
    The number of correctable memory errors reported against a memory DIMM has
    exceeded acceptable levels.
Automated Response
    Pages of memory associated with this memory DIMM are being removed from
    service as errors are reported.
Impact
    Total system memory capacity will be reduced as pages are retired.
Suggested Action for System Administrator
    Schedule a repair procedure to replace the affected memory DIMM, the identity
    of which can be determined using the command fmdump -v -u EVENT_ID.
Details
    The Message ID:   SUN4V-8000-DX indicates diagnosis has determined that a
    memory DIMM is faulty as a result of exceeding the threshold for correctable
    memory errors. Memory pages associated with the correctable errors have been
    retired and no data has been lost. However, the system is at increased risk
    of incurring an uncorrectable error, which will cause a service
    interruption, until the memory DIMM module is replaced.
    Use the command fmdump -v -u EVENT_ID with the EVENT_ID from the console
    message to locate the faulty DIMM. For example:
    fmdump -v -u f92e9f9e-735e-c218-cf87-9e1720a28004
    TIME                UUID                                SUNW-MSG-ID
    Sep 14 10:09:46.2234 f92e9f9e-735e-c218-cf87-9e1720a28004 SUN4V-8000-DX
    95%  fault.memory.dimm
    FRU: mem:///component=MB/CMP0/CH0:R0/D0/J0601
    rsrc: mem:///component=MB/CMP0/CH0:R0/D0/J0601
    In this example, the DIMM location is:
  
```

MB/CMP0/CH0:R0/D0/J0601

Refer to the Service Manual or the Service Label attached to the server chassis to find the physical location of the DIMM. Once the DIMM has been replaced, use the Service Manual for instructions on clearing the fault condition and validating the repair action.

NOTE - The server Product Notes may contain updated service procedures. The latest version of the Service Manual and Product Notes are available at the Sun Documentation Center.

3. Follow the suggested actions to repair the fault.

3.5.2 Clearing PSH Detected Faults

When the Solaris PSH facility detects faults, the faults are logged and displayed on the console. After the fault condition is corrected, for example by replacing a faulty FRU, you must clear the fault.

Note – If you are dealing with faulty DIMMs, do not follow this procedure. Instead, perform the procedure in [Section 5.5.2, “Installing DIMMs” on page 5-16](#).

1. After replacing a faulty FRU, power on the server.
2. At the ALOM CMT prompt, use the `showfaults` command to identify PSH detected faults.

PSH detected faults are distinguished from other kinds of faults by the text: Host detected fault.

Example:

```
sc> showfaults -v
ID Time                FRU                Fault
0 SEP 09 11:09:26    MB/CMP0/CH0/R1/D0 Host detected fault, MSGID:
SUN4U-8000-2S  UUID: 7ee0e46b-ea64-6565-e684-e996963f7b86
```

- If no fault is reported, you do not need to do anything else. Do not perform the subsequent steps.
- If a fault is reported, perform [Step 2](#) through [Step 4](#).

3. Run the `clearfault` command with the UUID provided in the `showfaults` output:

```
sc> clearfault 7ee0e46b-ea64-6565-e684-e996963f7b86
Clearing fault from all indicted FRUs...
Fault cleared.
```

4. Clear the fault from all persistent fault records.

In some cases, even though the fault is cleared, some persistent fault information remains and results in erroneous fault messages at boot time. To ensure that these messages are not displayed, perform the following command:

```
fmadm repair UUID
```

Example:

```
# fmadm repair 7ee0e46b-ea64-6565-e684-e996963f7b86
```

3.6 Collecting Information From Solaris OS Files and Commands

With the Solaris OS running on the server, you have the full compliment of Solaris OS files and commands available for collecting information and for troubleshooting.

If POST, ALOM, or the Solaris PSH features do not indicate the source of a fault, check the message buffer and log files for notifications for faults. Hard drive faults are usually captured by the Solaris message files.

Use the `dmesg` command to view the most recent system message. To view the system messages log file, view the contents of the `/var/adm/messages` file.

3.6.1 Checking the Message Buffer

1. Log in as superuser.

2. Issue the `dmesg` command:

```
# dmesg
```

The `dmesg` command displays the most recent messages generated by the system.

3.6.2 Viewing System Message Log Files

The error logging daemon, `syslogd`, automatically records various system warnings, errors, and faults in message files. These messages can alert you to system problems such as a device that is about to fail.

The `/var/adm` directory contains several message files. The most recent messages are in the `/var/adm/messages` file. After a period of time (usually every ten days), a new `messages` file is automatically created. The original contents of the `messages` file are rotated to a file named `messages.1`. Over a period of time, the messages are further rotated to `messages.2` and `messages.3`, and then deleted.

1. Log in as superuser.

2. Issue the following command:

```
# more /var/adm/messages
```

3. If you want to view all logged messages, issue the following command:

```
# more /var/adm/messages*
```

3.7 Managing Components With Automatic System Recovery Commands

The Automatic System Recovery (ASR) feature enables the server to automatically configure failed components out of operation until they can be replaced. In the server, the following components are managed by the ASR feature:

- UltraSPARC T1 processor strands
- Memory DIMMS
- I/O bus

The database that contains the list of disabled components is called the ASR blacklist (*asr-db*).

In most cases, POST automatically disables a faulty component. After the cause of the fault is repaired (FRU replacement, loose connector reseated, and so on), you must remove the component from the ASR blacklist.

The ASR commands (TABLE 3-7) enable you to view, and manually add or remove components from the ASR blacklist. These commands are run from the ALOM CMT *sc>* prompt.

TABLE 3-7 ASR Commands

Command	Description
<code>showcomponent</code> *	Displays system components and their current state.
<code>enablecomponent</code> <i>asrkey</i>	Removes a component from the <i>asr-db</i> blacklist, where <i>asrkey</i> is the component to enable.
<code>disablecomponent</code> <i>asrkey</i>	Adds a component to the <i>asr-db</i> blacklist, where <i>asrkey</i> is the component to disable.
<code>clearasrdb</code>	Removes all entries from the <i>asr-db</i> blacklist.

* The `showcomponent` command might not report all blacklisted DIMMS.

Note – The components (*asrkeys*) vary from system to system, depending on how many cores and memory are present. Use the `showcomponent` command to see the *asrkeys* on a given system.

Note – A reset or power cycle is required after disabling or enabling a component. If the status of a component is changed with power on there is no effect to the system until the next reset or power cycle.

3.7.1 Displaying System Components

The `showcomponent` command displays the system components (*asrkeys*) and reports their status.

- **At the *sc>* prompt, enter the `showcomponent` command.**

Example with no disabled components:

```
sc> showcomponent

Keys:
.
.
.

ASR state: clean
```

Example showing a disabled component:

```
sc> showcomponent

Keys:
.
.
.

ASR state: Disabled Devices
           MB/CMP0/CH3/R1/D1 : dimm8 deemed faulty
```

3.7.2 Disabling Components

The `disablecomponent` command disables a component by adding it to the ASR blacklist.

1. At the `sc>` prompt, enter the `disablecomponent` command.

```
sc> disablecomponent MB/CMP0/CH3/R1/D1

SC Alert:MB/CMP0/CH3/R1/D1 disabled
```

2. After receiving confirmation that the `disablecomponent` command is complete, reset the server so that the ASR command takes effect.

```
sc> reset
```


3.7.3 Enabling Disabled Components

The `enablecomponent` command enables a disabled component by removing it from the ASR blacklist.

1. At the `sc>` prompt, enter the `enablecomponent` command.

```
sc> enablecomponent MB/CMP0/CH3/R1/D1  
  
SC Alert:MB/CMP0/CH3/R1/D1 reenabled
```

2. After receiving confirmation that the `enablecomponent` command is complete, reset the server so that the ASR command takes effect.

```
sc> reset
```

3.8 Exercising the System With SunVTS

Sometimes a server exhibits a problem that cannot be isolated definitively to a particular hardware or software component. In such cases, it might be useful to run a diagnostic tool that stresses the system by continuously running a comprehensive battery of tests. Sun provides the SunVTS software for this purpose.

This section describes the tasks necessary to use SunVTS software to exercise your server:

- [Section 3.8.1, “Checking Whether SunVTS Software Is Installed”](#) on page 3-49
- [Section 3.8.2, “Exercising the System Using SunVTS Software”](#) on page 3-50

3.8.1 Checking Whether SunVTS Software Is Installed

This procedure assumes that the Solaris OS is running on the server, and that you have access to the Solaris command line.

1. Check for the presence of SunVTS packages using the `pkginfo` command.

```
% pkginfo -l SUNWvts SUNWvtsr SUNWvtsts SUNWvtsmn
```

- If SunVTS software is installed, information about the packages is displayed.

- If SunVTS software is not installed, you see an error message for each missing package.

```
ERROR: information for "SUNWvts" was not found
ERROR: information for "SUNWvtsr" was not found
...
```

The following table lists the SunVTS packages:

Package	Description
SUNWvts	SunVTS framework
SUNWvtsr	SunVTS framework (root)
SUNWvtsts	SunVTS for tests
SUNWvtsmn	SunVTS man pages

If SunVTS is not installed, you can obtain the installation packages from the following places:

- Solaris Operating System DVDs
- Sun Download Center: <http://www.sun.com/oem/products/vts>

The SunVTS 6.1 software, and future compatible versions, are supported on the server.

SunVTS installation instructions are described in the *SunVTS User's Guide*.

3.8.2 Exercising the System Using SunVTS Software

Before you begin, the Solaris OS must be running. You also need to ensure that SunVTS validation test software is installed on your system. See [Section 3.8.1, "Checking Whether SunVTS Software Is Installed"](#) on page 3-49.

The SunVTS installation process requires that you specify one of two security schemes to use when running SunVTS. The security scheme you choose must be properly configured in the Solaris OS for you to run SunVTS. For details, refer to the *SunVTS User's Guide*.

SunVTS software features both character-based and graphics-based interfaces. This procedure assumes that you are using the graphical user interface (GUI) on a system running the Common Desktop Environment (CDE). For more information about the character-based SunVTS TTY interface, and specifically for instructions on accessing it by `tip` or `telnet` commands, refer to the *SunVTS User's Guide*.

SunVTS software can be run in several modes. This procedure assumes that you are using the default mode.

This procedure also assumes that the server is *headless*, that is, it is not equipped with a monitor capable of displaying bitmap graphics. In this case, you access the SunVTS GUI by logging in remotely from a machine that has a graphics display.

Finally, this procedure describes how to run SunVTS tests in general. Individual tests may presume the presence of specific hardware, or might require specific drivers, cables, or loopback connectors. For information about test options and prerequisites, refer to the following documentation:

- *SunVTS Test Reference Manual (SPARC)*
- *SunVTS Doc Supplement (SPARC)*

3.8.3 Using SunVTS Software

1. Log in as superuser to a system with a graphics display.

The display system should be one with a frame buffer and monitor capable of displaying bitmap graphics such as those produced by the SunVTS GUI.

2. Enable the remote display.

On the display system, type:

```
# /usr/openwin/bin/xhost + test-system
```

where *test-system* is the name of the server you plan to test.

3. Remotely log in to the server as superuser.

Use a command such as `rlogin` or `telnet`.

4. Start SunVTS software.

If you have installed SunVTS software in a location other than the default `/opt` directory, alter the path in the following command accordingly.

```
# /opt/SUNWvts/bin/sunvts -display display-system:0
```

where *display-system* is the name of the machine through which you are remotely logged in to the server.

The SunVTS GUI is displayed ([FIGURE 3-6](#)).





FIGURE 3-6 SunVTS GUI

5. Expand the test lists to see the individual tests.

The test selection area lists tests in categories, such as *Network*, as shown in [FIGURE 3-7](#). To expand a category, left-click the  icon (expand category icon) to the left of the category name.




FIGURE 3-7 SunVTS Test Selection Panel

6. (Optional) Select the tests you want to run.

Certain tests are enabled by default, and you can choose to accept these.

Alternatively, you can enable and disable individual tests or blocks of tests by clicking the checkbox next to the test name or test category name. Tests are enabled when checked, and disabled when not checked.

[TABLE 3-8](#) lists tests that are especially useful to run on this server.

TABLE 3-8 Useful SunVTS Tests to Run on This Server

SunVTS Tests	FRUs Exercised by Tests
cmttest, cputest, fputest, iutest, l1dcachetest, dtlbttest, and l2sramtest— <i>indirectly</i> : mptest, and systest	DIMMS, motherboard
disktest	Disks, cables, disk backplane
nettest, netlbttest	Network interface, network cable, CPU motherboard
pmemtest, vmemtest, ramtest	DIMMs, motherboard
serialtest	I/O (serial port interface)
hsc1bttest	Motherboard, system controller (Host to system controller interface)

7. (Optional) Customize individual tests.

You can customize individual tests by right-clicking on the name of the test. For example, in [FIGURE 3-7](#), right-clicking on the text string `ce0 (nettest)` brings up a menu that enables you to configure this Ethernet test.

8. Start testing.

Click the Start button that is located at the top left of the SunVTS window. Status and error messages appear in the test messages area located across the bottom of the window. You can stop testing at any time by clicking the Stop button.

During testing, SunVTS software logs all status and error messages. To view these messages, click the Log button or select Log Files from the Reports menu. This action opens a log window from which you can choose to view the following logs:

- **Information** – Detailed versions of all the status and error messages that appear in the test messages area.
- **Test Error** – Detailed error messages from individual tests.
- **VTS Kernel Error** – Error messages pertaining to SunVTS software itself. You should look here if SunVTS software appears to be acting strangely, especially when it starts up.
- **Solaris OS Messages** (`/var/adm/messages`) – A file containing messages generated by the operating system and various applications.
- **Log Files** (`/var/opt/SUNWvts/logs`) – A directory containing the log files.

Preparing for Servicing

This chapter describes how to prepare the server for servicing.

The following topics are covered:

- [Section 4.1, “Common Procedures for Parts Replacement” on page 4-1](#)

For a list of FRUs, see [Appendix A](#).

Note – Never attempt to run the system with the cover removed. The cover must be in place for proper air flow. The cover interlock switch immediately shuts the system down when the cover is removed.

4.1 Common Procedures for Parts Replacement

Before you can remove and replace parts that are inside the server, you must perform the following procedures:

- [Section 4.1.2, “Shutting the System Down” on page 4-2](#)
- [Section 4.1.3, “Removing the Server From a Rack” on page 4-3](#)
- [Section 4.1.4, “Performing Electrostatic Discharge \(ESD\) Prevention Measures” on page 4-5](#)
- [Section 4.1.5, “Removing the Top Cover” on page 4-5](#)

The corresponding procedures that you perform when maintenance is complete are described in [Chapter 6](#).

4.1.1 Required Tools

The server can be serviced with the following tools:

- Antistatic wrist strap
- Antistatic mat
- No. 2 Phillips screwdriver

4.1.2 Shutting the System Down

Performing a graceful shutdown ensures that all of your data is saved and the system is ready for restart.

1. Log in as superuser or equivalent.

Depending on the nature of the problem, you might want to view the system status or the log files, or run diagnostics before you shut down the system. Refer to the *Sun Fire T1000 Server Administration Guide* for log file information.

2. Notify affected users.

Refer to your Solaris system administration documentation for additional information.

3. Save any open files and quit all running programs.

Refer to your application documentation for specific information on these processes.

4. Shut down the OS.

At the Solaris OS prompt, issue the `uadmin` command to halt the Solaris OS and to return to the `ok` prompt.

```
# uadmin 2 0
WARNING: proc_exit: init exited
syncing file systems... done
Program terminated
ok
```

This command is described in the Solaris system administration documentation.

5. Switch from the system console prompt to the SC console prompt by issuing the `#.` (Hash-Period) escape sequence.

```
ok #.
sc>
```


6. Using the SC console, issue the `poweroff` command.

```
sc> poweroff -fy  
SC Alert: SC Request to Power Off Host Immediately.
```

Note – You can also use the Power On/Off button on the front of the server to initiate a graceful system shutdown.

Refer to the *Sun Fire T1000 Server Administration Guide* for more information about the ALOM `poweroff` command.

4.1.3 Removing the Server From a Rack

If the server is installed in a rack with the extendable slide rails (outer and middle section) that were supplied with the server, use this procedure to remove the server chassis from the rack.

1. (Optional) Issue the following command from the ALOM `sc>` prompt to locate the system that requires maintenance:

```
sc> setlocator on  
Locator LED is on.
```

Once you have located the server, press the Locator button to turn it off.

2. Check to see that no cables will be damaged or interfere when the server chassis is removed from the rack.
3. Disconnect the power cord from the power supply.

Note – After you have disconnected the power cord from the power supply, you must wait about five seconds before reconnecting the power cord to the power supply.

4. Disconnect all cables from the server and label them.
5. From the front of the server, unlock both mounting brackets and pull the server chassis out until the brackets lock in the open position (FIGURE 4-1).




FIGURE 4-1 Unlocking a Mounting Bracket

6. Press the gray release tab on both mounting brackets to release the right and left mounting brackets, then pull the server chassis out of the rails ([FIGURE 4-2](#)). The mounting brackets slide approximately 4 in. (10 cm) farther before disengaging.




FIGURE 4-2 Location of the Mounting Bracket Release Buttons

7. Set the chassis on a sturdy work surface.

4.1.4 Performing Electrostatic Discharge (ESD) Prevention Measures

1. Prepare an antistatic surface to set parts on during removal and installation.

Place ESD-sensitive components, such as the printed circuit boards, on an antistatic mat. The following items can be used as an antistatic mat:

- Antistatic bag used to wrap a Sun replacement part
- Sun ESD mat, part number 250-1088
- Disposable ESD mat (shipped with some replacement parts or optional system components)

2. Use an antistatic wrist strap.

4.1.5 Removing the Top Cover

Access to all field-replaceable units (FRUs) requires the removal of the top cover.

Note – Never run the system with the top cover removed. The top cover must be in place for proper air flow. The cover interlock switch immediately shuts the system down when the cover is removed.



Caution – The system supplies 3.3 Vdc standby power to the circuit boards even when the system is powered off if the AC power cord is plugged in.

1. Press the cover release button ([FIGURE 4-3](#)).
2. While pressing the release button, grasp the rear of the cover and slide the cover toward the rear of the server about one half inch (1.2 cm).
3. Lift the cover off the chassis.




FIGURE 4-3 Location of Top Cover Release Button

Replacing Field-Replaceable Units

This chapter describes how to remove and replace customer-replaceable field-replaceable units (FRUs) in the server.

The following topics are covered:

- [Section 5.1, “Replacing the Optional PCI-Express Card” on page 5-2](#)
- [Section 5.2, “Replacing the Fan Tray Assembly” on page 5-4](#)
- [Section 5.3, “Replacing the Power Supply” on page 5-5](#)
- [Section 5.4, “Replacing a Hard Drive” on page 5-7](#)
- [Section 5.5, “Replacing DIMMs” on page 5-14](#)
- [Section 5.6, “Replacing the Motherboard and Chassis” on page 5-20](#)
- [Section 5.7, “Replacing the Clock Battery” on page 5-22](#)

For a list of FRUs, see [Appendix A](#).

Note – Never attempt to run the system with the cover removed. The cover must be in place for proper air flow. The cover interlock switch immediately shuts the system down when the cover is removed.

5.1 Replacing the Optional PCI-Express Card

5.1.1 Removing the Optional PCI-Express Card

Use this procedure to remove the optional low-profile PCI-Express (PCI-E) card from the server.

1. Perform the procedures described in [Chapter 4](#).
2. Remove any cables that are attached to the card.
3. On the rear of the chassis, pull the release lever that secures the PCI-Express card to the chassis ([FIGURE 5-1](#)).




FIGURE 5-1 Releasing the PCI-Express Card Release Lever

- Carefully pull the PCI-Express card out of the connector on the PCI-Express card riser board and the note slot (FIGURE 5-2).




FIGURE 5-2 Removing and Installing the PCI-Express Card

- Place the PCI-Express card on an antistatic mat.

5.1.2 Installing the Optional PCI-Express Card

Use this procedure to replace the PCI-Express cards.

- Unpack the replacement PCI-Express card and place it on an antistatic mat.

Note – Only low-profile PCI-Express cards with low brackets fit into the chassis. There are a variety of PCI-Express cards on the market. Read the product documentation for your device for additional installation requirements and instructions that are not covered here.

- Insert the PCI-Express card into the connector on the PCI-Express riser board and the note slot (FIGURE 5-2).

3. On the rear of the chassis, engage the release lever to secure the card to the chassis (FIGURE 5-1).
4. Perform the procedures described in [Chapter 6](#).

5.2 Replacing the Fan Tray Assembly

5.2.1 Removing the Fan Tray Assembly

1. Perform the procedures described in [Chapter 4](#).
2. Disconnect the fan power cable from the motherboard.
3. Push in on the clasps on both sides of the fan assembly (FIGURE 5-3).




FIGURE 5-3 Removing the Fan Tray Assembly

4. Remove the fan assembly from the sheet metal mounting brackets.

5.2.2 Installing the Fan Tray Assembly

1. Unpack the replacement fan tray assembly and place it on an antistatic mat.
2. Align the fan tray assembly with the sheet metal mounting brackets and slide it into place until the clasps on each side lock it into place.
3. Reconnect the fan power cable to the motherboard.
4. Perform the procedures described in [Chapter 6](#).

5.3 Replacing the Power Supply

5.3.1 Removing the Power Supply

1. Perform the procedures described in [Chapter 4](#).
2. Disconnect the power cable from the motherboard and pull the cable through the midwall.
3. Pull the fastener up on the front of the power supply and remove the power supply from the chassis ([FIGURE 5-4](#)).




FIGURE 5-4 Removing the Power Supply

5.3.2 Installing the Power Supply

1. **Unpack the replacement power supply.**
2. **Slide the power supply into the chassis and engage the two alignment pins in the rear of the chassis that mate with the power supply.**
3. **Push the fastener down on the front of the power supply to lock it into place in the chassis (FIGURE 5-5).**




FIGURE 5-5 Installing the Power Supply

4. Redress the power cable through the midwall in the chassis and connect the cable to the motherboard.
5. Perform the procedures described in [Chapter 6](#).
6. At the `sc>` prompt, issue the `showenvironment` command to verify the status of the power supply.

5.4 Replacing a Hard Drive

- To remove a hard drive from a *single*-drive assembly, go to [Section 5.4.1, “Replacing a Hard Drive in a Single-Drive Assembly”](#) on page 5-8.
- To remove a hard drive from a *dual*-drive assembly, go to [Section 5.4.2, “Replacing a Hard Drive in a Dual-Drive Assembly”](#) on page 5-10.

5.4.1 Replacing a Hard Drive in a Single-Drive Assembly

5.4.1.1 Removing the Hard Drive in a Single-Drive Assembly

1. Perform the procedures described in [Chapter 4](#).
2. Disconnect the drive cable from the data/power connector at the rear of the hard drive ([FIGURE 5-6](#)).
3. Pull the fasteners up on the rear of the single-drive assembly and remove the assembly from the chassis ([FIGURE 5-6](#)).




FIGURE 5-6 Removing the Single-Drive Assembly

5.4.1.2 Installing the Hard Drive in a Single-Drive Assembly

1. Unpack the replacement single-drive assembly.
2. Slide the single-drive assembly into the chassis until it mates with the front of the chassis (FIGURE 5-7).




FIGURE 5-7 Installing the Single-Drive Assembly

3. Push the fasteners down to lock the drive assembly into place in the chassis.
4. Redress the cable through the midwall in the chassis.
5. Reconnect the data cable to the data/power connector on the drive (FIGURE 5-7).

If you have a dual-drive cable installed in your system, connect the DRIVE 0 connector on the cable to the data/power connector at the rear of the drive. Do not connect the DRIVE 1 connector on the cable to the data/power connector at the rear of the drive in a single-drive assembly.

6. Perform the procedures described in [Chapter 6](#).

7. Perform the necessary administrative tasks to reconfigure the hard drive.

The procedures that you perform at this point depend on how your data is configured. You might need to partition the drive, create file systems, or load data from backups.

5.4.2 Replacing a Hard Drive in a Dual-Drive Assembly

5.4.2.1 Removing a Hard Drive in a Dual-Drive Assembly

1. Perform the procedures described in [Chapter 4](#).

2. Disconnect the drive cable from the data and power connectors on the motherboard ([FIGURE 5-8](#)).




FIGURE 5-8 Location of Drive Power and Data Connectors on the Motherboard

3. Pull the fasteners up on the rear of the dual-drive assembly and remove the dual-drive assembly from the chassis (FIGURE 5-9).




FIGURE 5-9 Removing the Dual-Drive Assembly

4. Determine which of the two hard drives you want to remove.
 - The upper drive (drive 1) is typically the data drive or mirror drive.
 - The lower drive (drive 0) is typically the boot drive.
5. Remove the drive from the drive bracket.

If you are removing the lower drive, you must first remove the upper drive before you can remove the lower drive.

 - To remove the *upper* drive (drive 1):
 - a. Disconnect the drive cable from the data/power connector on the upper drive.
 - b. Push the drive toward the back of the drive bracket and lift the drive away from the bracket.
 - To remove the *lower* drive (drive 0):
 - a. Disconnect the drive cable from the data/power connector on the lower drive.
 - b. Push the drive toward the back of the drive bracket and lift the drive away from the bracket.

5.4.2.2 Installing the Hard Drive in a Dual-Drive Assembly

1. **Unpack the replacement hard drive.**
2. **Install the replacement drive in the drive bracket.**
 - To replace the *lower* drive (drive 0):
 - a. **Install the replacement drive in the lower drive slot in the drive bracket.**
 - b. **Push the drive firmly toward the front of the drive bracket until the hard drive is completely seated.**
 - c. **Plug the DRIVE 0 connector on the drive cable into the data/power connector on the lower drive.**

Make sure the connector is correctly oriented before plugging it into the data/power connector on the drive.
 - To replace the *upper* drive (drive 1):
 - a. **Install the replacement drive in the upper drive slot in the drive bracket.**
 - b. **Push the drive firmly toward the front of the drive bracket until the hard drive is completely seated.**
 - c. **Plug the DRIVE 1 connector on the drive cable into the data/power connector on the upper drive.**

Ensure that the connector is correctly oriented before plugging it into the data/power connector on the drive.
3. **Slide the drive assembly into the chassis until it mates with the front of the chassis (FIGURE 5-10).**




FIGURE 5-10 Installing the Dual-Drive Assembly

4. Push the fasteners down to lock the drive assembly into place in the chassis ([FIGURE 5-10](#)).
5. Redress the cable through the midwall in the chassis.
6. Route the drive data cables underneath the power supply cable.
7. Plug the power connector on the dual-drive cable to the power connector on the motherboard ([FIGURE 5-8](#)).
8. Plug the data connector marked *J5003* on the cable to the *J5003* data connector on the motherboard (the connector farthest from the power supply).
Refer to [FIGURE 5-8](#) for the location of the *J5003* data connector.
9. Plug the data connector marked *J5002* on the cable to the *J5002* data connector on the motherboard (the connector closest to the power supply).
Refer to [FIGURE 5-8](#) for the location of the *J5002* data connector.
10. Perform the procedures described in [Chapter 6](#).
11. Use the Solaris `format` utility to label the 2.5-inch SAS hard drives.
Refer to the *Labeling Unlabeled Hard Drives* document for those instructions.
12. Perform the necessary administrative tasks to reconfigure the hard drive.
The procedures that you perform at this point depend on how your data is configured. You might need to partition the drive, create file systems, load data from backups, or have the data updated from a RAID configuration.

5.5 Replacing DIMMs

5.5.1 Removing DIMMs

Note – Not all DIMMs detected as faulty and offlined by POST must be replaced. In service (maximum) mode, POST detects memory devices with errors that might be corrected with Solaris PSH. See [Section 3.4.5, “Correctable Errors Detected by POST”](#) on page 3-35.



Caution – This procedure requires that you handle components that are sensitive to static discharges that can cause the component to fail. To avoid this problem, follow the antistatic practices as described in [Chapter 4](#).

1. **Perform the procedures described in [Chapter 4](#).**
2. **Locate the DIMM that you want to remove.**
Use [FIGURE 5-11](#) and [TABLE 5-1](#) to identify the DIMM that you want to remove.




FIGURE 5-11 DIMM Locations

TABLE 5-1 maps the DIMM names that are displayed in faults to the socket numbers that identify the location of the DIMM on the motherboard. The Channel/Rank/DIMM locations (for example, CH0/R0/D0) are silkscreened on the board and on a label near the board.

TABLE 5-1 DIMM Names and Socket Numbers

Socket Number	DIMM Name Used in Messages*
J0501	CH0/R0/D0
J0601	CH0/R0/D1
J0701	CH0/R1/D0
J0801	CH0/R1/D1
J1001	CH3/R0/D0
J1101	CH3/R0/D1
J1201	CH3/R1/D0
J1301	CH3/R1/D1

* DIMM names in messages are displayed with the full name, such as MB/CMP0/CH0/R1/D1, but this table lists the DIMM name with the preceding MB/CMP0 omitted for clarity.

- Note the DIMM location so that you can install the replacement DIMM in the same socket.**
- Push down on the ejector levers on each side of the DIMM until the DIMM is released.**

5. Grasp the top corners of the DIMM and remove it from the motherboard.
6. Place the DIMM on an antistatic mat.

5.5.2 Installing DIMMs

Use the following guidelines and [FIGURE 5-11](#) and [TABLE 5-1](#) to plan the memory configuration of your server.

- Eight slots hold industry-standard DDR-2 memory DIMMs.
- The server accepts the following DIMM sizes:
 - 512 MB
 - 1 GB
 - 2GB
- All DIMMs installed must be the same size.
- DIMMs must be added four at a time.
- Rank 0 memory must be fully populated for the server to function.

1. **Unpack the replacement DIMMs and place them on an antistatic mat.**
2. **Ensure that the socket ejector tabs are in the open position.**
3. **Line up the replacement DIMM with the connector.**
4. **Push the DIMM into the socket until the ejector tabs lock the DIMM in place.**
5. **Perform the procedures described in [Chapter 6](#).**

Note – You must replace the top cover as instructed in the [Chapter 6](#) chapter before proceeding with these instructions. The top cover must be in place for ALOM CMT to detect that a DIMM has been replaced.

6. **Gain access to the ALOM `sc>` prompt.**

Refer to the *Advanced Lights Out Management (ALOM) CMT Guide* for instructions.

7. **Run the `showfaults -v` command to determine how to clear the fault.**

The method you use to clear a fault depends on how the fault is identified by the `showfaults` command.

- If the fault is a *host-detected fault* (displays a UUID), continue to [Step 8](#). For example:

```
sc> showfaults -v
ID Time          FRU          Fault
0 SEP 09 11:09:26 MB/CMP0/CH0/R0/D0 Host detected fault
MSGID:
SUN4V-8000-DX UUID: f92e9fbe-735e-c218-cf87-9e1720a28004
```

- If the fault resulted in the FRU being disabled, such as the following,

```
sc> showfaults -v
ID Time          FRU          Fault
1 OCT 13 12:47:27 MB/CMP0/CH0/R0/D0 MB/CMP0/CH0/R0/D0
deemed faulty and disabled
```

then run the `enablecomponent` command to enable the FRU:

```
sc> enablecomponent MB/CMP0/CH0/R0/D0
```

8. Perform the following steps to verify the repair:

- a. Set the virtual keyswitch to `diag` so that POST will run in Service mode.

```
sc> setkeyswitch diag
```

b. Issue the `poweron` command.

```
sc> poweron
```

c. Switch to the system console to view the POST output.

```
sc> console
```

Watch the POST output for possible fault messages. The following output is a sign that POST did not detect any faults:

```
.  
. .  
. .  
0:0>POST Passed all devices.  
0:0>  
0:0>DEMON: (Diagnostics Engineering MONitor)  
0:0>Select one of the following functions  
0:0>POST:Return to OBP.  
0:0>INFO:  
0:0>POST Passed all devices.  
0:0>Master set ACK for vbsc runpost command and spin...
```

Note – Depending on the configuration of ALOM CMT POST variables and whether POST detected faults or not, the system might boot, or the system might remain at the `ok` prompt. If the system is at the `ok` prompt, type `boot`.

d. Return the virtual keyswitch to normal mode.

```
sc> setkeyswitch normal
```

e. Issue the Solaris OS `fmadm faulty` command.

```
# fmadm faulty
```

No memory or DIMM faults should be displayed.

If faults are reported, refer to the diagnostics flow chart in [FIGURE 3-1](#) for an approach to diagnose the fault.

9. Obtain the ALOM CMT `sc>` prompt.

10. Run the `showfaults` command.

If the fault was detected by the host and the fault information persists, the output will be similar to the following example:

```
sc> showfaults -v
ID Time          FRU                      Fault
0 SEP 09 11:09:26 MB/CMP0/CH0/R0/D0 Host detected fault
MSGID:
SUN4V-8000-DX UUID: f92e9fbe-735e-c218-cf87-9e1720a28004
```

If the `showfaults` command does not report a fault with a UUID, then you do not need to proceed with the following steps because the fault is cleared.

11. Run the `clearfault` command.

```
sc> clearfault f92e9fbe-735e-c218-cf87-9e1720a28004
```

12. Switch to the system console.

```
sc> console
```

13. Issue the `fmadm repair` command with the UUID.

Use the same UUID that you used with the `clearfault` command.

```
# fmadm repair f92e9fbe-735e-c218-cf87-9e1720a28004
```

5.6 Replacing the Motherboard and Chassis

5.6.1 Removing the Motherboard and Chassis

The motherboard and chassis are replaced as a unit. Therefore, you must remove all FRUs and associated cables from your chassis, and install them in the new chassis.

1. **Perform the procedures described in [Chapter 4](#).**
2. **Remove the PCI-Express card.**
See [Section 5.1, “Replacing the Optional PCI-Express Card”](#) on page 5-2.
3. **Remove the fan tray assembly and cable.**
See [Section 5.2, “Replacing the Fan Tray Assembly”](#) on page 5-4.
4. **Remove the power supply and cable.**
See [Section 5.3, “Replacing the Power Supply”](#) on page 5-5.
5. **Remove the hard drive and cable.**
See [Section 5.4, “Replacing a Hard Drive”](#) on page 5-7.
6. **Remove all DIMMs from the motherboard assembly.**
See [Section 5.5, “Replacing DIMMs”](#) on page 5-14.
7. **Remove the socketed system configuration SEEPROM from the motherboard and place it on an antistatic mat.**

The system configuration SEEPROM contains the persistent storage for the host ID and Ethernet MAC addresses of the system, as well as the ALOM configuration including the IP addresses and ALOM user accounts, if configured. This information will be lost unless the system configuration SEEPROM is removed and installed in the replacement motherboard. The PROM does not hold the fault data, and this data is no longer accessible once the motherboard and chassis assembly is replaced.

The location of this SEEPROM is shown in [Appendix A](#).

5.6.2 Installing the Motherboard and Chassis

1. **Replace the PCI-Express card.**
See [Section 5.1, “Replacing the Optional PCI-Express Card”](#) on page 5-2.

- 2. Replace the fan tray assembly and cable.**
See [Section 5.2, “Replacing the Fan Tray Assembly”](#) on page 5-4.
- 3. Replace the power supply and cable.**
See [Section 5.3, “Replacing the Power Supply”](#) on page 5-5.
- 4. Replace the hard drive and cable.**
See [Section 5.4, “Replacing a Hard Drive”](#) on page 5-7.
- 5. Replace the memory DIMMs.**
See [Section 5.5, “Replacing DIMMs”](#) on page 5-14.
- 6. Replace the socketed system configuration SEEPROM.**
The location of this SEEPROM is shown in [Appendix A](#).
- 7. Perform the procedures described in Chapter 6.**
- 8. Boot the system and run POST to verify that the system is fully operational.**
See [Section 3.4, “Running POST”](#) on page 3-22.

5.7 Replacing the Clock Battery

5.7.1 Removing the Clock Battery on the Motherboard

1. Perform the procedures described in [Chapter 4](#).
2. Using a small flathead screwdriver, carefully pry the battery from the motherboard ([FIGURE 5-12](#)).




FIGURE 5-12 Removing the Clock Battery From the Motherboard

5.7.2 Installing the Clock Battery on the Motherboard

1. Unpack the replacement battery.
2. Press the new battery into the motherboard with the + facing upward ([FIGURE 5-13](#)).




FIGURE 5-13 Installing the Clock Battery on the Motherboard

3. Perform the procedures described in [Chapter 6](#).
4. Use the ALOM `setdate` command to set the day and time.

Use the `setdate` command before you power on the host system. For details about this command, refer to the *Advanced Lights Out Management (ALOM) CMT Guide*.

Finishing Up Servicing

This chapter describes how to finish up servicing the server.

The following topics are covered:

- [Section 6.1.1, “Replacing the Top Cover” on page 6-1](#)
- [Section 6.1.2, “Reinstalling the Server Chassis in the Rack” on page 6-1](#)
- [Section 6.1.3, “Applying Power to the Server” on page 6-2](#)

6.1 Final Service Procedures

This section provides the finishing tasks in servicing your server.

6.1.1 Replacing the Top Cover

1. **Place the top cover on the chassis.**

Set the cover down so that the cover hangs over the rear of the server by about an inch (2.5 cm).

2. **Slide the cover forward until it latches into place.**

6.1.2 Reinstalling the Server Chassis in the Rack

1. **Refer to the *Sun Fire T1000 Server Installation Guide* for installation instructions.**
2. **After you have reinstalled the server chassis in the rack, reconnect all cables that you disconnected when you removed the chassis from the rack.**

6.1.3 Applying Power to the Server

Note – If you have just disconnected the power cord from the power supply, you must wait about five seconds before reconnecting the power cord to the power supply.

- **Reconnect the power cord to the power supply.**

Note – As soon as the power cord is connected, standby power is applied. Depending on the configuration of the firmware, the system might boot.

Field-Replaceable Units

[FIGURE A-1](#) shows the locations of the field-replaceable units (FRUs) in the server. [TABLE A-1](#) lists the FRUs. Note that item number 4 in [FIGURE A-1](#) is a 3.5-inch SATA drive used in the single-drive configuration. The 2.5-inch SAS drives used in the dual-drive configuration look different, but would be installed in the same location in the server.




FIGURE A-1 Field-Replaceable Units

TABLE A-1 Server FRU List

Item No.	FRU	Replacement Instructions	Description	Location
1	Motherboard and chassis assembly	Section 5.6, "Replacing the Motherboard and Chassis" on page 5-20	The motherboard and chassis are replaced as a single assembly. The motherboard is provided in different configurations to accommodate the different processor models (6 core and 8 core).	MB
2	DIMMs	Section 5.5, "Replacing DIMMs" on page 5-14	Can be ordered in the following sizes: <ul style="list-style-type: none"> • 512 MB • 1 GB • 2 GB 	See TABLE 5-1 and FIGURE 5-11 .
3	Fan tray assembly	Section 5.2, "Replacing the Fan Tray Assembly" on page 5-4	A single assembly containing 4 fans.	FT0
4	Hard drives	Section 5.4, "Replacing a Hard Drive" on page 5-7	One of the following configurations: <ul style="list-style-type: none"> • One SATA disk drive, 3.5-inch form factor • Two SAS disk drives, 2.5-inch form factor 	HDD0 HDD1
5	Power supply unit (PS)	Section 5.3, "Replacing the Power Supply" on page 5-5	The power supply provides -3.3 Vdc standby power at 3 @ 3 Amps and 12 Vdc at 25 Amps.	PS0
6	PCI-Express card slot	Section 5.1, "Replacing the Optional PCI-Express Card" on page 5-2	Optional add-on express card.	PCIE0
7	Clock battery	Section 5.7, "Replacing the Clock Battery" on page 5-22	The battery is located on the motherboard.	MB/BAT
8	SEEPROM	Remove and replace the socketed SEEPROM.	The socketed SEEPROM contains the MAC address and system configuration information.	MB/SCC

Index

A

- AC OK LED, 3-4
- Advanced ECC technology, 3-7
- Advanced Lights Out Management (ALOM) CMT
 - connecting to, 3-13
 - diagnosis and repair of server, 3-11
 - POST, and, 3-23
 - prompt, 3-13
 - service related commands, 3-13
- airflow, blocked, 3-5
- ALOM CMT *see* Advanced Lights Out Management (ALOM) CMT
- antistatic mat, 1-2
- antistatic wrist strap, 1-2
- ASR blacklist, 3-47, 3-48
- asrkeys*, 3-47
- Automatic System Recovery (ASR), 3-46

B

- blacklist, ASR, 3-47
- bootmode command, 3-14
- break command, 3-14

C

- chipkill, 3-7
- clearasrdb* command, 3-47
- clearfault* command, 3-14, 3-45
- clearing POST detected faults, 3-38
- clearing PSH detected faults, 3-44
- clock battery
 - installing, 5-22

- removing, 5-22
- components, disabled, 3-47, 3-48
- components, displaying the state of, 3-47
- connecting to ALOM CMT, 3-13
- console, 3-14
- console command, 3-14, 3-29
- consolehistory command, 3-14

D

- DDR-2 memory DIMMs, 3-7
- diag_level* parameter, 3-23, 3-26
- diag_mode* parameter, 3-23, 3-26
- diag_trigger* parameter, 3-23, 3-26
- diag_verbosity* parameter, 3-23, 3-26
- diagnostics
 - low level, 3-22
 - running remotely, 3-11
 - SunVTS, 3-49
- DIMMs
 - example POST error output, 3-34
 - installing, 5-16
 - names and socket numbers, 5-15
 - removing, 5-14, 5-20
 - troubleshooting, 3-8
- disablecomponent* command, 3-47, 3-48
- disabled component, 3-48
- displaying FRU status, 3-19
- dmesg* command, 3-46

E

- electrostatic discharge (ESD) prevention, 1-2

- enablecomponent command, 3-39, 3-47, 3-49
- environmental faults, 3-4, 3-5, 3-13, 3-16
- event log, checking the PSH, 3-41
- exercising the system with SunVTS, 3-50

F

- fan status, displaying, 3-17
- fan tray assembly
 - installing, 5-5
 - removing, 5-4
- fault manager daemon, fmd (1M), 3-39
- fault message ID, 3-16
- fault records, 3-45
- faults, 3-12, 3-16
 - environmental, 3-4, 3-5
 - recovery, 3-12
 - repair, 3-12
 - types of, 3-16
- fmadm command, 3-45
- fmdump command, 3-41
- front panel
 - LED status, displaying, 3-17
- FRU ID PROMs, 3-12
- FRU status, displaying, 3-19

H

- hard drive
 - installing, 5-9, 5-12
 - removing, 5-8, 5-10
 - status, displaying, 3-17
- hardware components sanity check, 3-27
- help command, 3-14

I

- installing
 - clock battery, 5-22
 - DIMMs, 5-16
 - fan tray assembly, 5-5
 - hard drive, 5-9, 5-12
 - motherboard and chassis, 5-20
 - PCI-Express card, 5-3
 - power supply, 5-6
 - top cover, 6-1
- installing the server in the rack, 6-1

L

- LEDs
 - AC OK, 3-4
 - Power OK, 3-4
- log files, viewing, 3-46

M

- memory
 - configuration, 3-7
 - fault handling, 3-6
- message ID, 3-40
- messages file, 3-45
- motherboard and chassis
 - installing, 5-20
 - removing, 5-20

P

- PCI-Express card
 - installing, 5-3
 - removing, 5-2
- POST detected faults, 3-4, 3-16
- POST *see also* power-on self-test (POST), 3-22
- Power OK LED, 3-4
- power supply
 - installing, 5-6
 - removing, 5-5
- power supply status, displaying, 3-17
- powercycle command, 3-14, 3-28, 3-36
- powering down the system, 4-2
- powering on the system, 6-2
- poweroff command, 3-15
- poweron command, 3-15
- power-on self-test (POST), 3-5
 - about, 3-22
 - ALOM CMT commands, 3-23
 - configuration flow chart, 3-25
 - error message example, 3-34
 - error messages, 3-34
 - example output, 3-29
 - fault clearing, 3-38
 - faulty components detected by, 3-38
 - how to run, 3-28
 - parameters, changing, 3-26
 - reasons to run, 3-27
 - troubleshooting with, 3-6
- Predictive Self-Healing (PSH)

- about, 3-39
- clearing faults, 3-44
- memory faults, and, 3-8
- Sun URL, 3-40

PSH detected faults, 3-16

PSH *see also* Predictive Self-Healing (PSH), 3-39

R

removing

- clock battery, 5-22
- DIMMs, 5-14, 5-20
- fan tray assembly, 5-4
- hard drive, 5-8, 5-10
- motherboard and chassis, 5-20
- PCI-Express card, 5-2
- power supply, 5-5
- top cover, 4-5

removing the server from the rack, 4-3

required tools, 4-2

reset command, 3-15

resetsc command, 3-15

S

safety information, 1-1

safety symbols, 1-1

Service Required LED, 3-12, 3-39

setkeyswitch parameter, 3-15, 3-26

setlocator command, 3-15

showcomponent command, 3-47

showenvironment command, 3-15, 3-17

showfaults command, 3-4

- description and examples, 3-16
- syntax, 3-15
- troubleshooting with, 3-5

showfru command, 3-15, 3-19

showkeyswitch command, 3-15

showlocator command, 3-15

showlogs command, 3-15

showplatform command, 3-15

Solaris log files, 3-4

Solaris OS

- collecting diagnostic information from, 3-45

Solaris Predictive Self-Healing (PSH) detected faults, 3-4

SunVTS, 3-2, 3-4

- exercising the system with, 3-50
- running, 3-51
- tests, 3-53
- user interfaces, 3-50

support, obtaining, 3-5

syslogd daemon, 3-46

system console, switching to, 3-14

system temperatures, displaying, 3-17

T

top cover

- installing, 6-1
- removing, 4-5

troubleshooting

- actions, 3-4
- DIMMs, 3-8

U

UltraSPARC T1 multicore processor, 3-40

Universal Unique Identifier (UUID), 3-39

V

virtual keyswitch, 3-26

voltage and current sensor status, displaying, 3-17

